# EMERSON

## XRi77CX - XRi77CH

## Digital controller for variable speed drive

## FW 23.2

1.	GENERAL WARNING	
2.	GENERAL DESCRIPTION	
3.	CONTROLLING LOADS	
4.	PULL DOWN	
5.	EVAPORATOR FAN CONTROL	
6.	CONDENSER FAN CONTROL	
7.	AUXILIARY REGULATOR	
8.	DUAL MAP FEATURE	
9.	VARIABLE SPEED COMPRESSOR CONTROL	
10.	FRONT PANEL AND COMMANDS	3
11.	MAX & MIN TEMPERATURE MEMORIZATION	
12.	MAIN FUNCTIONS	3
13.	PARAMETERS	3
14.	DIGITAL INPUTS	
15.	RS485 SERIAL LINE – FOR MONITORING SYSTEMS	
16.	INSTALLATION AND MOUNTING	
17.	ELECTRICAL CONNECTIONS	
18.	HOW TO USE THE HOT KEY	
19.	ALARM SIGNALS	
20.	TECHNICAL DATA	6
21.	WIRINGS	
22.	DEFAULT SETTING VALUES	7

### 1. GENERAL WARNING

### 1.1 PLEASE READ BEFORE USING THIS MANUAL

- This manual is part of the product and should be kept near the instrument for easy and quick
  reference.
- The instrument shall not be used for purposes different from those described hereunder. It cannot be used as a safety device.
- Check the application limits before proceeding.
- Dixell Srl reserves the right to change the composition of its products, even without notice, ensuring the same and unchanged functionality.

### 1.2 SAFETY PRECAUTIONS

- Check the supply voltage is correct before connecting the instrument.
- Do not expose to water or moisture: use the controller only within the operating limits avoiding sudden temperature changes with high atmospheric humidity to prevent condensation
- Warning: disconnect all electrical connections before any kind of maintenance.
- Fit the probe where it is not accessible by the End User. The instrument must not be opened.
   In case of failure or faulty operation send the instrument back to the distributor or to "Dixell S.r.l." (see address) with a detailed description of the fault.
- Consider the maximum current which can be applied to each relay (see Technical Data).
- Ensure that the wires for probes, loads and the power supply are separated and far enough from each other, without crossing or intertwining.
- In case of applications in industrial environments, the use of mains filters (our mod. FT1) in parallel with inductive loads could be useful.

## 2. GENERAL DESCRIPTION

Model **XRi77CX-CH**, format 32x74mm, is microprocessor-based controller, suitable for applications on medium or low temperature ventilated refrigerating units. It has four relay outputs to control compressor, fan, defrost, which can be either electrical or reverse cycle (hot gas) and light (configurable). It could be provided with a Real Time Clock which allows programming of up to 6 daily defrost cycles, divided into holidays and workdays. A "Day and Night" function with two different set points is fitted for energy saving. It is also provided with up to four NTC probe inputs. The first probe is used for temperature control. The second probe is used to control the defrost termination temperature at the evaporator. One of the two digital inputs can operate as third temperature probe. The fourth probe is used to control the condenser temperature (for condenser alarm management) or to display a temperature.


The RS485 serial output allows connecting the unit to a network line (ModBUS-RTU compatible) such as any Dixell monitoring units of X-WEB family. The HOT-KEY receptacle allows programming the controller by using an HOTKEY programming device.

The instrument is fully configurable through special parameters that can be easily programmed through the frontal keyboard.

### 3. CONTROLLING LOADS

### 3.1 COMPRESSOR

The regulation is performed according to the temperature measured by the thermostat probe with a positive differential (**HY**) over the set point: if the temperature increases and reaches set point plus differential, the compressor will start. It will turn off as soon as the temperature reaches the set point value again.



In case of fault in the thermostat probe the start and stop of the compressor are timed through parameters  ${\sf Con}$  and  ${\sf CoF}.$ 

### 3.2 DEFROST

Two defrost modes are available through the tdF parameter: defrost through electrical heater (tdF=EL) and hot gas defrost (tdF=in).

- The defrost interval depends on the presence of the RTC (optional). The internal RTC is controlled by means of the EdF parameter:
  - EdF=in: the defrost is made every idF time standard way for controller without RTC.
- EdF=rtC: the defrost is real time controlled, depending on the hours set in the parameters Ld1...Ld6 (for workdays).
   Other parameters are used to control defrosting cycles: the maximum length (MdF) and defrosting

modes: timed or controlled by the evaporator's probe (P2P). At the end of defrost dripping time is started, its length is set in the Fdt parameter. With Fdt=0 the dripping time is disabled.

#### 3.2.1 PRE-DEFROST

The par. dAF enable a pre-defrost phase. During this interval the regulation setpoint will be moved to the value SET-1°C (or SET-1°F). The defrost phase starts as soon as the regulation temperature reach the pre-defrost setpoint or when the dAF timer ends. This function is disable when dAF=0.

## 3.2.2 HOT GAS DEFROST

- If tdF=in, the defrost phase will act as follow:
- If dSd>0, the compressor output will be deactivated
- At the end of dSd interval, the defrost output will be activated and timer StC will start
- At the end of StC interval, the compressor output will be reactivated.

## If dSd=0 or StC=0, the relative functions will be disabled.

#### 3.3 CONTROL OF EVAPORATOR FANS

The fan control mode is selected by means of the FnC parameter:

- FnC=C\_n, fans will switch ON and OFF with the compressor and not run during defrost.
- FnC=o\_n, fans will run even if the compressor is off, and not run during defrost.

After a defrost, there is a timed fan delay allowing for drip time, set by means of the **Fnd** parameter. - **FnC=C\_Y** fans will switch ON and OFF with the compressor and **run** during defrost.

FnC=o\_Y, fans will run continuously also during defrost.

An additional parameter **FSt** provides the setting of temperature, detected by the evaporator probe, above which the fans are always OFF. This is used to make sure circulation of air only if his temperature is lower than set in **FSt**.

#### 3.3.1 FORCED ACTIVATION OF FANS

This function managed by the **FCt** parameter is designed to avoid short cycles of fans, that could happen when the controller is switched on or after a defrost, when the room air warms the evaporator. **How it works:** if the temperature difference between evaporator probe and room probe is higher than the **FCt** parameter value, fans will be switched on. With **FCt=0** the function is disabled.

#### 3.3.2 CYCLIC ACTIVATION OF THE FANS WITH COMPRESSOR OFF

When **FnC=C-n** or **C-Y** (fans working in parallel with the compressor), by means of the **Fon** and **FoF** parameters the fans can carry out on and off cycles even if the compressor is switched off. When the compressor is stopped the fans go on working for the **Fon** time. With **Fon=0** the fans remain always off, also when the compressor is off.

## 3.4 RELAY CONFIGURATION (PAR. OA0, OA1, OA2, OA3)

The functioning of the configurable relays (terminals 1-2 and 1-7-8) can be set by the **oA1** and **oA2** parameters, according to the kind of application. In the following paragraph the possible setting:

### 3.4.1 LIGHT RELAY

With oAx=LiG the related relay operates as light output.

#### 3.4.2 AUXILIARY RELAY

Relay activation by digital input 1 or digital input 2 (oAx=AUS, i1F or i2F=AUS): with oAx=AUS and i1F, i2F=AUS the AUX relay is switched on and off by digital inputs.

#### 3.4.3 ON/OFF RELAY (OAX = ONF)

When oAx=onF, the related relay is activated when the controller is turned on and de-activated when the controller is turned off.

#### 3.4.4 NEUTRAL ZONE REGULATION

With oAx=db the related relay can control a heater element to perform a neutral zone action.

oAx cut in = SET-HY

### oAx cut out = SET

3.4.5 ALARM RELAY

With oAx=AIr the related relay operates as alarm relay. It is activated every time an alarm happens. Its status depends on the tbA parameter: if tbA=Y, the relay is silenced by pressing any key. If tbA=n, the alarm relay stays on until the alarm condition recovers.

#### 3.4.6 SECOND COMPRESSOR

If oAx=CP2, it will work as second compressor output. The anti-short cycle parameter AC1 gives the possibility to desynchronize the compressor activations.

#### 3.4.7 SECOND DEFROST OUTPUT

If oAx=dF2, it will work as second defrost output.

NOTE: It is also possible to manage 2 different and independent defrost by using special parameter map. Please refer to Dixell to activate this function.

#### 3.4.8 NIGHT BLINDS MANAGEMENT DURING ENERGY SAVING CYCLES

With oAx=HES, the related relay operates to manage the night blind: the relay is energised when the energy saving cycle is activated by digital input or frontal button.

#### 3.4.9 HEATER FOR WATER DRIPPING

If oAx=Het, the related output will work as heater for water dripping during and after any defrost.

## Installing and operating instructions

# EMERSON

## 3.4.10 REGULATION OUTPUT

If  $oAx{=}inV,$  the related output will work as regulation output and will stay active as soon as the regulation request is running.

## 4. PULL DOWN

An automatic function named PULL-DOWN is implemented. This function forces the controller to work at **PMA** until reaching a specific SETPOINT (par. **CCS**) for a maximum interval of time (par. **CCt**). The PULL-DOWN function is activated:

At start-up if the temperature measured from the regulation probe is higher than the SETPOINT After any defrost

If the temperature measured from regulation probe go over the SET+HY+HY1+oHt value. If one of the above conditions happens, the controller will maintain the maximum compressor speed

(PMA) until reaching the CCS setpoint. The maximum interval of time for any PULLDOWN is defined from par. CCt.

## 5. EVAPORATOR FAN CONTROL

The evaporator fan control mode is selected by means of the **FnC** parameter:

FnC = C\_n: fans will switch ON and OFF with the compressor and not run during defrost
 FnC = o\_n: fans will run even if the compressor is off, and not run during defrost

After defrost, there is a timed fan delay allowing for drip time, set by means of the Fnd parameter.

- FnC = C\_Y: fans will switch ON and OFF with the compressor and run during defrost
- FnC = o\_Y: fans will run continuously also during defrost

The par. **FAP** is used to select which temperature probe will be used from the evaporator fan regulator. A specific setpoint (par. **FSt**) provides the temperature value, detected by the evaporator probe, above which the fans are always OFF. This is used to make sure circulation of air only if his temperature is lower than set in **FSt-HYF**.

## 5.1 FORCED ACTIVATION FOR FANS

This function, managed by the **FCt** parameter, is designed to avoid short cycles of fans, that could happen when the controller is switched on or after a defrost, when the room air warms the evaporator. If the difference between the evaporator temperature and the room temperature is higher than the **FCt** value, the controller will activate the fans. This function is disabled if **FCt=0**.

# 5.2 CYCLIC ACTIVATION OF THE FANS WHEN THE COMPRESSOR IS SWITCHED OFF

When FnC=C-n or C-Y (fans in parallel to the compressor), the fans will be able to carry out on and off cycles even if the compressor is switched off. The on and off interval of time follow the Fon and FoF parameters. When the compressor is stopped, the fans will go on working for the Fon time. On the other side, with Fon=0 the fans will stay always off when the compressor is off.

## 6. CONDENSER FAN CONTROL

The condenser fan control mode is selected by means of the FCC parameter:

- FCC = C\_n: fans will switch ON and OFF with the compressor and not run during defrost
- FCC = o\_n: fans will run even if the compressor is off, and not run during defrost
- FCC = C\_Y: fans will switch ON and OFF with the compressor and run during defrost
- FCC = o\_Y: fans will run continuously also during defrost

The par. FAC is used to select which temperature probe will be used from the condenser fan regulator. This regulator uses a specific setpoint (par. St2) and differential (par. HY2) to activate and deactivate the condenser fans:

- If T>St2+HY2 the condenser fans are activated
- If T<St2 the condenser fans are deactivated

The par. FCo can be used to keep the ventilators active for a period after compressor OFF.

## 7. AUXILIARY REGULATOR

The auxiliary regulator can be be linked to a digital output (relay) for ONOFF regulation. The parameters used to configure the auxiliary regulators are the following:

ACH	Kind of action for auxiliary regulator
SAA	Set point for auxiliary regulator
SHY	Differential for auxiliary regulator
ArP	Probe selection for auxiliary regulator
Sdd	Auxiliary regulator disabled during any defrost

## 8. DUAL MAP FEATURE

The controller is programmed with 2 different parameter maps. In this way, it is possible to choose the right map to meet both LT and NT applications. There are two different way to do this:

- If i1F=nt, it will be possible to change the working map by using the digital input. By using the **DOWN** button, if it is linked to the map changing function. If so, keep it pressed 3
- sec to activate the relative function.

## 9. VARIABLE SPEED COMPRESSOR CONTROL

## 9.1 FREQUENCY MODE

The controller can drive variable speed compressors with frequency control input. The frequency output port can issue a frequency signal from 30 to 200Hz, duty cycle=50%. A special cable must be used in order to connect the frequency output of the controller to the frequency input of the specific inverter.

- CAB/EM1: cable DD900002 20 for Embraco VNEK/U models

CAB/SE1: cable DD900002 22 for SECOP NLV models

NOTE:

An inverter compressor can be completely controlled from the frequency output only.
 Only one compressor can be connected when frequency mode is used

## 9.2 PARAMETERS

The following parameters are used to set the regulation:

CME Continuous mode during Energy Saving Mode: (n; Y)

HY1	Differential for proportional regulation: (0.1 to 25.5°C; 1 to 45°F)
Fr0	Frequency output value with compressor stopped: (0 to 50Hz) frequency output signal when compressor stopped
PMi	Minimum compressor speed (in percentage): (0 to PMA)
PMA	Maximum compressor speed (in percentage): (PMi to 100%)
voS	Signal output variation (increment) when temperature is increasing: if vdC=FrE then 1 to 100 Hz, otherwise 10 to 1000 rpm
vo2	Signal output variation (decrement) when temperature is decreasing: if vdC=FrE then 1 to 100 Hz, otherwise 10 to 1000 rpm
vo3	Signal output variation (decrement) after any Pull Down: if vdC=FrE then 1 to 100 Hz, otherwise 10 to 1000 rpm
t1F	Time with compressor at PMI before stopping regulation: (0 to 999 min)
SPi	Compressor speed (in percentage) in case of any error probe: (PMi to PMA)
CMn	Continuous mode during Normal Mode: (n; Y)

The value of the par HY1 can normally be set to the same value of par. HY. In this way, the regulation band will be extended from SET to SET+HY+HY1. The device will activate the regulation when the measured temperature will go over the SET+HY value and will stop the regulation when the temperature will reach the SET value. When the regulation is running, the frequency output, and then the compressor speed, will be calculated in proportional way by using the PMi...PMA band. After reaching the SET+HY value, the controller will start increasing the frequency output, and then the equivalent compressor speed, by using the par. voS. The speed increasing will be stopped as soon as the proportional calculated value (for the compressor speed) hooks the requested value. In case of temperature decrement and compressor speed higher than the new requested value, the controller will decrease the compressor speed proportionally by using the vo2 value. After any Pull Down, and in case of continuous mode regulation (CMn or CME=Y) it is possible to speed up the compressor speed decrement by using par. vo3. This helps to avoid subfreezing conditions due to high compressor speed after reaching the regulation setpoint.

After reaching the SET value it is possible to force the compressor speed to **Pmi** for t1F min. In case of any regulation probe error, the compressor speed will be set to the value of par. **SPi**. It is possible to enable a cyclic or a continuous mode operation both during normal mode or energy saving mode:

CMn, CME = Y: after reaching the SETPOINT the VSC will keep on running CMn, CME = n: after reaching the SETPOINT the VSC will be stopped (after t1F)

### 9.3 TEMPERATURE DEADLOCK CONTROL

The controller can detect temperature deadlocks. If the actual speed is not able to reach the SETPOINT, and if this condition persists for a long interval of time, then the controller will increment the actual speed until reaching the SETPOINT. A differential (par. **th1**) and a speed increment (par. **oFS**) is used to detect and manage any deadlock condition.

#### 9.4 HOT GAS DEFROST

In case of using hot-gas defrost, it will be possible to set the compressor speed by using par. Aod.

## 9.5 PULL DOWN

An automatic function named PULL DOWN is implemented. This function forces the controller to work at **PMA** until reaching a specific SETPOINT (par. **CCS**) for a maximum interval of time (par. **CCt**). The PULL-DOWN function is activated:

 At start-up if the temperature measured from the regulation probe is higher than the SET+HY+HY1

After any defrost

If the temperature measured from regulation probe go over the SET+HY+HY1+oHt value.

If one of the above conditions happens, the controller will maintain the maximum compressor speed (PMA) until reaching the CCS setpoint. The maximum interval of time for any PULLDOWN is defined from par. CCt. At the end of any PULL DOWN it is possible to set an interval of time (par. t1F) with predefined compressor speed (PMi).

## 9.6 OIL MIGRATION CONTROL (VALID ONLY FOR VSC)

To avoid oil migration during variable speed compressor operation, a lubrication control is implemented. If the compressor works with a speed lower than the MnP threshold for tMi time, then the compressor speed will be increased to PMA for tMA time. NOTES:

NUTES:

- MnP= PMi to PMA, nu, OFF If MnP=nu, then this function is disabled
- IT WINF=NU, THEN THIS TUNCTION IS DISABL

If MnP=oFF, then the compressor will be stopped for tMA if it works continuously for tMi

### 9.7 STEP REGULATION: VSD AND ONOFF COMPRESSOR

The following parameters are used to set up the step regulation function:

Pon	Step regulation: inverter compressor speed during ton (in percentage)
SCd	Step regulation: deactivation of the ONOFF compressor
ton	Step regulation: delay before activation of the second compressor (when T> SET + HY + HY1)
toF	Step regulation: delay before deactivation of the second compressor
don	Step regulation: minimum operating time of the second compressor
doF	Step regulation: minimum stop time of the second compressor

# The step regulation is activated when at least one ONOFF compressor is enabled (oAx=CP1 or CP2) and oAn=FrE.

The second compressor (the ONOFF one) will be activated when T > SET+HY+HY1. The ONOFF compressor deactivation follows par. **SCd**.

¥

## Installing and operating instructions

## FRONT PANEL AND COMMANDS

 $\triangleright$ 

ധ



1.	Push and immediately release the SET key: the display will show the Set point value
2.	Push and immediately release the SET key or wait for 5 sec to display the probe value again

#### 12.3 HOW TO CHANGE THE SET POINT

- Push the SET button for 3 sec to change the Set point value. 1.
- 2 The value of the set point will be displayed and the °C or °F icon will start blinking
- 3 Use the UP or DOWN buttons to modify the current value
- Use the SET button to store the new value into memory Δ

### 12.4 HOW TO START A MANUAL DEFROST

Keep the DEF button pressed for 3 sec to start a manual defrost.

#### 12.5 HOW TO ENTER PARAMETER PROGRAMMING MENU "PR1"

#### Follow these steps Enter the Programming mode by pressing the SET+DOWN buttons for 3 sec (the °C or °F LED 1

- will start blinking)
- 2 Browse to the required parameter and then press the SET button to display its current value 3 Use UP or DOWN buttons to change its value
- 4. Press SET button to store the new value and move to the following parameter

To exit: press SET+UP buttons or wait for 15 sec without pressing any key.

NOTE: the set value is stored even when the procedure exits by waiting for the time-out

#### 12.6 HOW TO ENTER PARAMETER PROGRAMMING MENU "PR2"

The manufacturer menu (Pr2) includes all the parameters of the instrument

#### ENTERING THE PARAMETER PROGRAMMING MENU "PR2" 12.6.1

- Enter the Programming mode by pressing the SET+DOWN buttons for 3 sec (the °C or °F icon 1. will start blinking)
- 2 Released the buttons and then push again the SET+DOWN buttons for more than 7 sec. The Pr2 label will be displayed immediately followed from the HY parameter.

#### NOW THE PARAMETER MENU "PR2" IS AVAILABLE FOR ANY MODIFICATION

- 3 Browse to the required parameter
- Press the SET button to display its value. 4
- 5 Use UP or DOWN to change its value
- 6. Press SET to store the new value and move to the following parameter.

To exit: press SET+DOWN or wait for 15 sec without pressing any key

NOTE1: if no parameter is present in Pr1 menu, after 3 sec the "noP" message will be displayed. Keep the buttons pushed till the Pr2 message will be displayed.

NOTE2: the set value is stored even when the procedure ends by waiting for the time-out

12.6.2 HOW TO MOVE A PARAMETER FROM "PR2" MENU TO "PR1" MENU AND VICE-VERSA

Each parameter present in the hidden menu (Pr2) can be moved into the user level (Pr1) by pressing both SET+DOWN buttons. If a parameter is part of the user level, when showed in the hidden menu the decimal point will be lit.

#### HOW TO LOCK THE KEYBOARD 12.7

- Keep both UP and DOWN buttons pressed more than 3 sec.
- 2. The "PoF" message will be displayed, and the keyboard will be locked. At this point it will be possible only to see the set point or the MAX o Min temperature stored
- 3 If a button is pressed more than 3 sec the "PoF" message will be displayed

#### 12.8 HOW TO: UNLOCK THE KEYBOARD

Keep both UP and DOWN pressed more than 3 sec till the "Pon" message will be displayed.

#### 12.9 THE ON/OFF FUNCTION



By pushing the  $\ensuremath{\text{ON/OFF}}$  key, the instrument will go in stand-by During the stand-by status, all the relays are switched OFF and the regulations are stopped

if a monitoring system is connected, it does not record the instrument data and alarms

WARNING: Loads connected to the normally closed contacts of the relays are always supplied and under voltage, even if the instrument is in stand-by mode.

#### PARAMETERS 13.

rtC	Real time clock menu (only for controller with RTC): to set the time and date and defrost start time.		
GULAT	ION		
LS	Minimum set point: (-100°C to SET; -148°F to SET) sets the minimum value for the set point.		
US	Maximum set point: (SET to 150°C; SET to 302°F) set the maximum value for set point.		
ΗY	Differential for normal regulation (compressor cut-in): (0.1 to 25.5°C; 1 to 45°F) differential for set point. Compressor Cut IN is Set Point + differential (HY). Compressor Cut OUT is when the temperature reaches the set point.		
odS	Outputs delay activation after power on: (0 to 255min) this function is enabled at the initial start-up of the instrument and inhibits any output activation for the period set in the parameter.		
AC	Compressor anti-short-cycle delay: (0 to 50min) minimum interval between the compressor stop and the following restart.		
AC1	Second compressor anti-short-cycle delay: (0 to 50min) minimum interval between the second compressor stop and the following restart		

SET	To display target set point; in programming mode it selects a parameter or confirm an operation.
XIX	(DEF) To start a manual defrost.
$\land$	(UP) To see the used parameter map. When in programming mode, it browses the parameter codes or increases the displayed value.
$\bigtriangledown$	(DOWN) To see the used parameter map. When in programming mode, it browses the parameter codes or decreases the displayed value. Keep it pressed 5 sec to change parameter map from "nt" to "Lt" and vice-versa (valid when button properly configured).
Ú	To switch the instrument on and off (when <b>onF=oFF</b> ).
Ŷ.	To switch on and off the light (when <b>oAx=LiG</b> ).

#### **KEY COMBINATIONS:**

SEI +	To exit the programming mode
	<b>-</b>
SET + 🏷	To enter in programming mode
$\land + \bigtriangledown$	To lock & unlock the keyboard

#### 10.1 USE OF LEDS

Icon functions are described in the following table

LED	MODE	FUNCTION
*	ON	Compressor enabled
*4*	Flashing	Anti-short cycle delay enabled
*	ON	Defrost enabled
••••	Flashing	Drip time in progress
ş	ON	Fans enabled
	Flashing	Fans delay after defrost in progress.
()	ON	An alarm is occurring
*	ON	A PULL DOWN is running
ECO	ON	Energy saving enabled
ġ.	ON	Light on
AUX	ON	Auxiliary relay on
°C°E	ON	Measurement unit
<b>Ľ</b> , <b>/</b> –	Flashing	Programming phase

### 11. MAX & MIN TEMPERATURE MEMORIZATION

11.1 HOW TO SEE THE MIN TEMPERATURE

- Press and release the DOWN button (if properly configurated). 1
- 2 The "Lo" message will be displayed followed by the minimum temperature recorded. 3. By pressing the DOWN button again or waiting for 5 sec the normal display will be restored.

#### 11.2 HOW TO SEE THE MAX TEMPERATURE

- Press and release the UP button (if properly configurated).
- The "Hi" message will be displayed followed by the maximum temperature recorded. 2 3 By pressing the UP button again or waiting for 5 sec the normal display will be restored.

#### 11.3 HOW TO RESET THE MAX AND MIN TEMPERATURE RECORDED

- Keep SET button pressed for more than 3 sec while the max or min temperature is displayed. 1. ("rSt" message will be displayed)
- After confirming the operation, the "rSt" message will start blinking and then the normal 2 temperature will be displayed

## 12. MAIN FUNCTIONS

12.1 TO SET THE CURRENT TIME AND DAY (ONLY WITH RTC)

- When the instrument is switched on, it could be required to set the real-time clock.
- Enter the Pr1 programming menu by keeping both SET+DOWN buttons pressed for 3 sec. 1 Browse to the rtC menu and then push the SET key to enter the real time clock menu.
- 2 3.
- The Hur (hour) parameter is displayed. 4.
- Push the SET and set current hour by the UP and DOWN keys, then push SET to confirm the value 5.
- Repeat the same operations with Min (minutes) and dAy (day) parameters and other parameters

To exit: Push both SET+UP buttons or wait for 15 sec without pushing any button.

# Installing and operating instructions

MCo	Maximum time with compressor active: (0 to 255 min) if compressor working tin is over MCo, it will be stopped. MCo=0 means function disabled.
rtr	F(P1; P2) percentage for regulation: (0 to 100; 100=P1, 0=P2) it allows to set t regulation according to the percentage of the first and second probe, as for t following formula (rtr(P1-P2)/100 + P2).
CCt	Maximum duration for Pull Down: (0.0 to 24h00min, res. 10min) allows setting t length of the PULL-DOWN cycle. Compressor stays on without interruption during C time. This is useful, for instance, when the room is filled with new products.
CCS	Differential for Pull Down: (-12 to 12°C; -21 to 21°F) relative value to add to t regulation SETPOINT and to use during any PULL-DOWN cycle.
oHt	Threshold for automatic activation of Pull Down in normal mode: (0.0 to 25.5° 0 to 45°F) upper threshold for auto activation of a PULL DOWN
Con	Compressor ON time with faulty probe: (0 to 255min) time during which the compressor is active in case of faulty thermostat probe. With Con=0 compressor always OFF.
CoF	Compressor OFF time with faulty probe: (0 to 255min) time during which the compressor is OFF in case of faulty thermostat probe. With CoF=0 compressor always active.
Pon	Inverter compressor speed during ton (in percentage): 0 to 100%
SCd	Deactivation of the ONOFF compressor: (th1; th2) define when ONOFF compressor is stopped. th1=when T <set+hy; t<set<="" td="" th2="" when=""></set+hy;>
ton	Delay before activation of the second compressor (when T> SET + HY + HY1): 0 to 255 sec
toF	Delay before deactivation of the second compressor: 0 to 255 sec
	Minimum operating time of the second compressor: 0 to 255 sec

HY1	Differential for normal regulation (compressor cut-in): (0.1 to 25.5°C; 1 to 45°F)	
Fr0	Frequency output value with compressor stopped: ([0 Hz ÷ FMi])	
PMi	Minimum drive speed (in percentage): (0 to PMA)	
PMA	Maximum drive speed (in percentage): (PMi to 100%)	
voS	Compressor speed variation (increment) when temperature is increasing: (1 100 Hz/min, StP) StP = means that inverter speed is adapted immediately of temperature variation	
vo2	Compressor speed variation (decrement) when temperature is decreasing: (0 100 Hz/min, StP, nu) StP = means that inverter speed is adapted immediately of temperature variation; nu = speed decrement disabled	
vo3	Compressor speed variation (decrement) after any Pull Down: (0 to 100 Hz/mi StP, nu) StP = means that inverter speed is adapted immediately on temperatur variation; nu = speed decrement disabled	
PdP	Variable Speed Drive (in percentage) during any Pull Down: 0 to 100 %	
t1F	Time with Variable Speed Drive at minimum before stopping it: 0 to 999 min	
Spi	Variable Speed Drive (in percentage) in case of any error probe: PMi to PMA	
Aod	Variable Speed Drive (in percentage) during any defrost: PMi to PMA	
AoF	Variable Speed Drive (in percentage) during a pre-defrost phase: PMi to PMA	
tH1	Differential for deadlock control: 0.1 to 1.0°C	
oFS	Compressor speed increment during any deadlock condition: 1 to 10Hz	
CMn	Continuous mode regulation when normal mode: (n; Y)	
CME	Continuous mode regulation when energy saving mode: (n; Y)	
MnP	Minimum compressor speed for activating lubrication control (valid only for Variable Speed Drive): (nu, 1÷99%, OFF) nu = function disabled; OFF = compress is stopped for tMA time	
tMi	Compressor running time below the MnP threshold: (0.0 to 24h00min)	
tMA	Lubrication control interval: 0 to 255 min	
DBES		
DES		
PbC	Temperature probe selection: ntC; PtC; PT1000	
ot	Probe P1 calibration: (-12.0 to 12.0°C; -21 to 21°F) allows to adjust possible offs of the thermostat probe.	
P2P	<b>Probe P2 presence:</b> (n; Y) <b>n</b> = not present, the defrost stops by time; <b>Y</b> = present, the defrost stops by temperature.	
οE	Probe P2 calibration: (-12.0 to 12.0°C; -21 to 21°F) allows to adjust possible offs of the evaporator probe.	
P3P	Probe P3 presence: (n; Y) n = not present, the terminals 18-20 operate as digit input; Y = present, the terminals 18-20 operate as third probe.	
o3	Probe P3 calibration: (-12.0 to 12.0°C; -21 to 21°F) allows to adjust possible offs of the third probe.	
P4P	Probe P4 presence: (n; Y) n = not present; Y = present	
	Probe P4 calibration: (-12.0 to 12.0°C; -21 to 21°F) allows to adjust possible offs	

CF	Temperature measurement unit: (°C; °F) °C = Celsius; °F = Fahrenheit. WARNING: When the measurement unit is changed the SET point and the values of the parameters HY, LS, US, ot, ALU and ALL have to be checked and modified (if necessary).
rES	Resolution for °C: (in=1°C; dE=0.1°C) allows decimal point display.
Lod	Probe visualized (P1; P2, P3, P4, SET, dtr) it selects which probe is displayed by the instrument. P1 = Thermostat probe; P2 = Evaporator probe; P3 = Third probe (only for model with this option enabled); P4 = Fourth probe, SET = set point; dtr = percentage of visualization.
dLY	Temperature visualization delay: (0 to 20min00s; res. 10 sec) when the temperature increases, the display is updated of 1°C or 1°F after this time.
dtr	Visualization percentage=F(P1;P2): (1 to 99; 99=P1, 1=P2) if Lod=dtr it allows to set the visualization according to the percentage of the first and second probe, as for the following formula (dtr(P1-P2)/100 + P2).
DEFROST	
EdF	Defrost mode (only for controller with RTC): rtC=Real Time Clock mode. Defrost time follows dd1dd6 and Ld1Ld6 parameters on working days. in=interval mode. The defrost starts when the time idF is expired.

The delitost starts when the time for is ex
1592020670 XRi77CX-CH GB r1.1 15.10.2019
1332020070 XIXI77CX-CIT GD 11.1 13.10.2013

truo	ctions EMERSON
tdF	<b>Defrost type:</b> (EL; in) EL = electrical heater; in = hot gas.
dFP	Probe selection for defrost control: (nP; P1; P2; P3; P4) nP = no probe; P1 =thermostat probe; P2 = evaporator probe; P3 =configurable probe; P4 = Probe o Hot Key plug.
dtE	Defrost end temperature: (-55 to 50°C; -67 to 122°F) (enabled only when EdF=Pb sets the temperature measured by the evaporator probe, which causes the end c defrost.
idF	Interval between two consecutive defrost cycles: (0 to 120 hours) determines th interval of time between two defrost cycles.
MdF	Maximum length for any defrost: (0 to 255min) when P2P=n, (not evaporator probe timed defrost) it sets the defrost duration. When P2P=Y (defrost end based of temperature) it sets the maximum length for defrost.
dSd	Start defrost delay: (0 to 255 sec) when a defrost starts, the compressor will be stopped and the defrost output delayed. If dSd=0 this function is disabled.
StC	Compressor stop before activating any defrost: (0 to 255 sec) is used to delay th compressor restart when the defrost is managed for inversion of cycle (hot-gas).
dFd Displaying during any defrost: (rt; it; Set; dEF) rt = real temperature; it = temperature at defrost start; Set = set point; dEF = "dEF" label.	
dAd	Delay for display temperature update after any defrost: (0 to 255min) sets th maximum time between the end of a defrost and the beginning of the visualization of the real room temperature.
Fdt	Draining time: (0 to 120min) time interval between reaching defrost terminatio temperature and the restoring of the control's normal operation. This time allows th evaporator to eliminate water drops that might have formed due to defrost.
Hon	Time with drain heater activated after drainig time Fdt (valid is oAx=HEt): (0.0 t 24h00min, res. 10 min) the heating elements stay on for this time after finishing th dripping phase.
dPo	Defrost after power on: (n; Y) n = after the idF time or following RTC, Y = immediately
dAF	Pre-defrost time: (0 to 255 min) it is used to sub freeze the goods before activatin any defrost. The regulation setpoint is modified to SET-1°C or SET-2°F during thi interval. If dAF=0 this function is disabled.
NS	
FAP	Probe selection for evaporator fan: (nP; P1; P2; P3; P4) nP = no probe; P1 =thermostat probe; P2 = evaporator probe; P3 =configurable probe; P4 = Probe o Hot Key plug.
FSt	Evaporator fan stop temperature: (-50 to 50°C: -55 to 122°F) setting of temperature

	Hot Key plug.			
FSt	Evaporator fan stop temperature: (-50 to 50°C; -55 to 122°F) setting of temperature, detected by evaporator probe, above which fans are always OFF.			
HY	Differential for evaporator fan regulator: (0.1 to 25.5°C; 1 to 45°F)			
FnC	Evaporator fan mode operation: (C-n; o-n; C-Y; o-Y) C-n = runs with the compressor, OFF during defrost; o-n = continuous mode, OFF during defrost; C-Y = runs with the compressor, ON during defrost; o-Y = continuous mode, ON during defrost.			
Fnd	Evaporator fan delay after defrost: (0 to 255min) interval between the end of a defrost and the next evaporator fans start.			
FCt	Temperature differential for evaporator fan activation: (0 to 59°C; 0 to 90°F) (N.B.: FCt=0 means function disabled) if the difference of temperature between the evaporator and the room probes is higher than FCt value, the fans will be switched on.			
Ft	Evaporator fan controlled during any defrost: (n;Y)			
Fon	Evaporator fan ON in normal mode (with compressor OFF): (0 to 15min) with Fnc=C_n or C_Y, (fan activated in parallel with compressor) it sets the evaporator fan ON cycling time when the compressor is off. With Fon=0 and FoF≠0 the fan are always off, with Fon=0 and FoF=0 the fan are always off.			
FoF	Evaporator fan OFF in normal mode (with compressor OFF): (0 to 15min) With $FnC=C_n$ or $C_2Y$ , (fan activated in parallel with compressor) it sets the evaporator fan off cycling time when the compressor is off. With Fon=0 and FoF≠0 the fan are always off, with Fon=0 and FoF=0 the fan are always off.			
FAC	Probe selection for condenser fan: (nP; P1; P2; P3; P4) nP = no probe; P1 =thermostat probe; P2 = evaporator probe; P3 =configurable probe; P4 = Probe on Hot Key plug.			
St2	Set Point for condenser fan regulator: (-100.0 to 150.0°C; -148 to 302°F)			
HY2	Differential for condenser fan regulator: (0.1 to 25,5°C; 1 to 45°F)			
FCC	Condenser fan mode operation: (C-n; o-n; C-Y; o-Y) C-n = runs with the compressor, OFF during defrost; o-n = continuous mode, OFF during defrost; C-Y = runs with the compressor, ON during defrost; o-Y = continuous mode, ON during defrost			
FCo	Condenser fan activated when compressor off (valid if FCC=C-n, C-Y): (0 to 999 sec.			

## AUXILIARY

sec

	-			
ACH	Type of action for auxiliary regulator: (CL; Ht) CL=cooling; Ht = heating			
SAA Set point for auxiliary regulator: (-100.0 to 150.0°C; -148 to 302°F)				
SHY				
ArP Probe selection for auxiliary regulator: (nP; P1; P2; P3; P4) nP = no probe; P1 =thermostat probe; P2 = evaporator probe; P3 =configurable probe; P4 = Prol Hot Key plug.				
Sdd	Auxiliary regulator disabled during any defrost: (n; Y) n=the auxiliary relay operates during defrost. Y=the auxiliary relay is switched off during defrost.			
ALARMS				
ALP	ALP         Temperature alarm probe selection: (nP; P1; P2; P3; P4) nP = no probe, the temperature alarms are disabled; P1 = Probe 1 (Thermostat probe); P2 = Probe 2 (evaporator probe);           P3 = Probe 3 (display probe); P4 = Fourth probe.			
ALC Temperature alarms configuration: (Ab; rE) Ab = absolute temperature is given by the ALL or ALU values. rE = temperature alarm: to the set point. Temperature alarm is enabled when the temperature [SET+ALU] or [SET-ALU] values.				
ALU	Maximum temperature alarm: If ALC=Ab: [ALL to 150.0°C or ALL to 302°F] If ALC=rE: [0.0 to 50.0°C or 0 to 90°F] when this temperature is reached the alarm is enabled, after the Ald delay time.			

## Installing and operating instructions

## EMERSON

ALL	Minimum temperature alarm:
	If ALC=Ab: [-100°C to ALU; -148 to ALU];
	If ALC=rE: [0.0 to 50.0°C or 0 to 90°F] when this temperature is reached the alarm is
	enabled, after the Ald delay time.
AFH	Differential for temperature alarm recovery: (0.1 to 25.5°C; 1 to 45°F) intervention differential for recovery of temperature alarm.
ALd	Temperature alarm delay: (0 to 255 min) time interval between the detection of an alarm condition and alarm signalling.
dAo	Temperature alarm delay after power-on: (0.0 to 24h00min, res. 10min) time interval between the detection of the temperature alarm condition after instrument power on and alarm signalling.
ONDENS	SER TEMPERATURE ALARM
AP2	Second temperature alarm probe selection: (nP; P1; P2; P3; P4)
	nP = no probe; P1 = thermostat probe; P2 = evaporator probe; P3 = configurable probe;
	P4 = Probe on Hot Key plug.
AL2	Second low temperature alarm (absolute value): (-100 to 150°C; -148 to 302°F)
	when this temperature is reached the LA2 alarm is signalled, possibly after the Ad2
	delay.
Au2	Second high temperature alarm (absolute value): (-100 to 150°C; -148 to 302°F)
	when this temperature is reached the HA2 alarm is signalled, possibly after the Ad2
	delay.
AH2	Differential for second temperature alarm recovery: 0.1 to 25.5°C; 1 to 45°F
Ad2	Second temperature alarm delay: (0 to 255 min) time interval between the detection of the condenser alarm condition and alarm signalling.
dA2	Second temperature alarm activation delay after power-on: 0.0 to 24h00min, res. 10min.
bLL	Compressor off due to second low temperature alarm: (n; Y) n = compressor keeps
	on working; Y = compressor is switched off till the alarm is present, in any case
	regulation restarts after AC time at minimum.
AC2	Compressor off due to second high temperature alarm: (n; Y) n = compressor
	keeps on working; Y = compressor is switched off till the alarm is present, in any case
	regulation restarts after AC time at minimum.
SAF	Differential for anti-freezing control: (0.0 to 25.5°C; 1 to 45°F) low level threshold to

CONFIGURABLE RELAYS

stop regulation

- oA1
   Relay oA1 configuration (7-8): (dEF; Fan; Alr; LiG; AUS; onF; db; CP2; dEF2; HES; Het; inV, CMP, nu) dEF = defrost; Fan = do not select it; Alr = alarm; LiG = light; AUS = Auxiliary relay: onF = always on with instrument on; db = neutral zone; CP2 = second compressor output; dF2 = do not select it; HES = night blind; Het = heater output; inV = inverter compressor; CMP = ONOFF compressor; nu=not used.

   oA2
   Relay oA2 configuration (4-5-6); (dEF: Fan; Alr; LiG; AUS; onF; db; CP2; dEF2; HES;
- oA2 Relay oA2 configuration (4-5-6): (dEF; Fan; Alr; LiG; AUS; onF; db; CP2; dEF2; HES; Het; inV, CMP, nu) dEF = defrost; Fan = do not select it; Alr = alarm; LiG = light; AUS = Auxiliary relay; onF = always on with instrument on; db = neutral zone; CP2 = second compressor output; dF2 = do not select it; HES = night blind; Het = heater output; inV = inverter compressor; CMP = ONOFF compressor; nu=not used.
- oA3 Relay oA3 configuration (8-9): (dEF; Fan; Alr; LiG; AUS; onF; db; CP2; dEF2; HES; Het; inV, CMP, nu) dEF = defrost; Fan = do not select it; Alr = alarm; LiG = light; AUS = Auxiliary relay; onF = always on with instrument on; db = neutral zone; CP2 = second compressor output; dF2 = do not select it; HES = night blind; Het = heater output; inV = inverter compressor; CMP = ONOFF compressor; nu=not used.
- oA4 Relay oA4 configuration (10-11-12): (dEF; Fan; AIr; LiG; AUS; onF; db; CP2; dEF2; HES; Het; inV, CMP, nu) dEF = defrost; Fan = do not select it; AIr = alarm; LiG = light; AUS = Auxiliary relay; onF = always on with instrument on; db = neutral zone; CP2 = second compressor output; dF2 = do not select it; HES = night blind; Het = heater output; inV = inverter compressor; CMP = ONOFF compressor; nu=not used.
   oAn Analogue output configuration: (n;Y) n = 5-pin port is used for HOT-KEY; Y = 5-pin
- port is used as frequency output. AoP Alarm relay polarity: (oP; CL) oP = the relay is activated by opening the contact; CL
- = the relay is activated by closing the contact.

#### DIGITAL INPUTS

i1P	Digital input 1 polarity: (oP; CL) oP = the digital input is activated by opening the contact; CL = the digital input is activated by closing the contact.
i1F	Digital input 1 configuration: (EAL; bAL; dor; dEF; ES; AUS; Htr; HdF; onF; nt) EAL = external alarm: "EA" message is displayed; bAL = serious alarm "CA" message is displayed; dor = door switch function; dEF = activation of a defrost cycle; ES = energy saving; AUS = auxiliary relay activation with oAx=AUS; Htr = type of inverting action (cooling or heating); HdF =do not set it; onF = to switch the controller off; nt = to change parameter map
i2P	<b>Digital input 2 input polarity:</b> (oP; CL) oP = the digital input is activated by opening the contact; CL = the digital input is activated by closing the contact.
i2F	Digital input 2 configuration: (EAL; bAL; dor; dEF; ES; AUS; Htr; HdF; onF; nt) EAL = external alarm: "EA" message is displayed; bAL = serious alarm "CA" message is displayed; dor = door switch function; dEF = activation of a defrost cycle; ES = energy saving; AUS = auxiliary relay activation with oAx=AUS; Htr = type of inverting action (cooling or heating); HdF =do not set it; onF = to switch the controller off; nt = to change parameter map
did	Digital input 1 alarm delay: (0 to 255 min) delay between the detection of the external alarm condition and its signalling. When i1F= PAL, it is the interval of time to calculate the number of pressure switch activation.
d2d	Digital input 2 alarm delay: (0 to 255 min) delay between the detection of the external alarm condition and its signalling. When i1F= PAL, it is the interval of time to calculate the number of pressure switch activation.
nPS	Number of pressure alarm events before stopping the regulation (Lock alarm): (1 to 15) after nPS activations of the ixF=BAL digital input the regulation will be stopped.
odC	Compressor and fan status after door opening: (no; Fan; CPr; F_C) no = normal; Fan = normal; CPr = compressor OFF, $F_C$ = compressor OFF.

	rrd	<b>Regulation restart after open door alarm:</b> (n; Y) n = outputs follow the odC parameter. Y = outputs restart with a door open alarm.		
	HES Differential for energy saving mode: (-30.0 to 30.0°C; -54 to 54°F) it sets the increasing value of the set point [SET+HES] during the Energy Saving cycle.			
	LdE Energy saving mode controls the lights (lights off when energy saving goes active): (n, Y) n= lights are independent from energy saving; Y = lights are turned OFF when energy saving mode is activated			
CU	IRRENT	TIME AND WEEKLY HOLIDAYS (ONLY FOR MODELS WITH RTC)		
[	Hur	Hours: 0 to 23h		
	Min	Minutes: 0 to 59min		
	dAY	Day of the week: Sun to Sat		
	dYM	Day of the month: 1 to 31		
	Mon	Month: 1 to 12		
	YAr	Year: 0 to 99		
	Hd1	Hd1 First day of weekend: (Sun to Sat; nu) set the first day of the week which follows the holiday times.		
	Hd2 Second day of weekend: (Sun to Sat; nu) set the second day of the week which follows the holiday times.			
N.E	3. Hd	1, Hd2 can be set also as "nu" value (Not Used).		
EN	ERGY S	SAVING TIMES (ONLY FOR MODELS WITH RTC)		
Γ	il E	Working days Energy saving starting time: (0 to 23550min) during the Energy		

iLE	Working days Energy saving starting time: (0 to 23h50min) during the Energy Saving cycle the set point is increased by the value in HES so that the operation set point is SET+HES.	
dLE	Working days Energy saving duration: (0 to 24h00min) sets the duration of the Energy Saving cycle on workdays.	
iSE Holyday Energy saving starting time: 0 to 23h50min.		
dSE	Holyday Energy saving duration: 0 to 24h00min.	

### DEFROST TIMES (ONLY FOR MODELS WITH RTC)

dd1dd6	Daily defrost: (n; Y) to enable the Ld1Ld6 defrost operations for all the days of the week.
Ld1Ld6	<b>Defrost starting time:</b> (0 to 23h50min) these parameters set the beginning of the 6 programmable defrost cycles during workdays. Ex: when Ld2=12.4 the second defrost starts every Monday at 12.40.

N.B.: <u>To disable a defrost cycle set it to "nu"(not used).</u> Ex: if Ld6=nu; the sixth defrost cycle will be disabled.

#### OTHER Serial address: (1 to 247) identifies the instrument address when connected to a Adr ModBUS compatible monitoring system. onC ONOFF button configuration: (nu; oFF; ES) nu=not used; oFF=to switch OFF and ON the controller: ES=to enable and disable enersy saving mode **ONOFF button timed (3sec) configuration:** (nu; oFF; ES) nu=not used; oFF=to switch OFF and ON the controller; ES=to enable and disable enersy saving mode on2 LG2 Light button timed (3sec) configuration (left upper side): (nu; LiG; AUS; Lnt) nu=not used; LiG= to activate and deactivate light output; AUS=to activate and deactivate the auxiliary output; Lnt=to change parameter map Down button timed (3sec) configuration: (nu; Std; Lnt; Pnd) nu=not used; dn2 Std=standard use; Lnt= to change parameter map; Pdn=to activate a Pull Down cycle. dP1 Probe P1 value visualization: read only dP2 Probe P2 value visualization: read only dP3 Probe P3 value visualization: read only dP4 Probe P4 value visualization: read only SPd Instantaneous Variable Speed Drive speed (in percentage): read only Real set point: it shows the set point used during the energy saving cycle or during rSE the continuous cvcle. rEL Firmware release for internal use. Ptb Parameter table code: readable only.

## 14. DIGITAL INPUTS

The first digital input (terminals 18-20) is enabled with P3P=n.

With P3P=n and i1F=i2F the second digital input is disabled.

The free voltage digital inputs are programmable by the i1F and i2F parameters.

### 14.1 GENERIC ALARM (IXF = EAL)

As soon as the digital input is activated the unit will wait for **did** time delay before signalling the "EAL" alarm message. The outputs status doesn't change. The alarm stops just after the digital input is deactivated.

#### 14.2 SERIOUS ALARM MODE (IXF = BAL)

When the digital input is activated, the unit will wait for **did** delay before signalling the "**CA**" alarm message. The relay outputs are switched OFF. The alarm will stop as soon as the digital input is deactivated.

#### 14.3 DOOR SWITCH INPUT (IXF = DOR)

It signals the door status and the corresponding relay output status through the **odC** parameter: **no** = normal (any change); **FAn** = Fan OFF; **CPr** = Compressor OFF; **F\_C** = Compressor and fan OFF. Since the door is opened, after the delay time set through parameter **doA**, the door alarm is enabled, the display shows the message **dA** and <u>the regulation restarts is</u> **rtr=Y**. The alarm stops as soon as the external digital input is disabled again. With the door open, the high and low temperature alarms are disabled.

#### 14.4 START DEFROST (IXF = DEF)

It starts a defrost if there are the right conditions. After the defrost is finished, the normal regulation will restart only if the digital input is disabled otherwise the instrument will wait until the **MdF** safety time is expired.

## Installing and operating instructions

14.5 SWITCH THE AUXILIARY RELAY (IXF = AUS)

## With oAx=AUS the digital input switched the status of the auxiliary relay

14.6 INVERSION OF THE KIND OF ACTION: HEATING-COOLING (IXF = HTR)

This function allows inverting the regulation of the controller: from cooling to heating and viceversa.

### 14.7 ENERGY SAVING (IXF = ES)

The Energy Saving function allows to change the set point value as the result of the [SET+HES] (parameter) sum. This function is enabled until the digital input is activated.

14.8 ON OFF FUNCTION (IXF = ONF)

To switch the controller on and of

14.9 CHANGE PARAMETER MAP (IXF = NT)

To move from LT to NT parameter map.

#### 14.10 DIGITAL INPUTS POLARITY

The digital input polarity depends on the i1P and i2P parameters.

- i1P or i2P=CL, the input is activated by closing the contact.
- i1P or i2P=OP, the input is activated by opening the contact.

## **RS485 SERIAL LINE – FOR MONITORING SYSTEMS**

The RS485 serial line allows connecting the instrument to a monitoring system (ModBUS-RTU compatible).

## 16. INSTALLATION AND MOUNTING



Instrument XRi77CX-CH shall be mounted on vertical panel, in a 29x71 mm hole, and fixed using the special bracket supplied. The temperature range allowed for correct operation is 0 to 60°C. Avoid places subject to strong vibrations, corrosive gases, excessive dirt or humidity. The same recommendations apply to probes. Let air circulate by the cooling holes.



## 17. ELECTRICAL CONNECTIONS

The instrument is provided with screw terminal block to connect cables with a cross section up to 2.5mm2. Before connecting cables make sure the power supply complies with the instrument's requirements. Separate the probe cables from the power supply cables, from the outputs and the power connections. Do not exceed the maximum current allowed on each relay, in case of heavier loads use a suitable external relay.

#### 17.1 PROBE CONNECTION

The probes shall be mounted with the bulb upwards to prevent damages due to casual liquid infiltration. It is recommended to place the thermostat probe away from air streams to correctly measure the average room temperature. Place the defrost termination probe among the evaporator fins in the coldest place, where most ice is formed, far from heaters or from the warmest place during defrost, to prevent premature defrost termination

## 18. HOW TO USE THE HOT KEY

To enable the HOT-KEY port (5-pin connector), set the par. oAn=n.

PROGRAM A HOT KEY FROM AN INSTRUMENT (UPLOAD) 18.1

- Program one controller with the front keypad
- When the controller is ON, insert the "HOT-KEY" and push UP button; the "uPL" message 2.
- appears followed a by a flashing "End" label. Push SET button and the "End" will stop flashing.
- 4. Turn OFF the instrument, remove the "HOT-KEY" and then turn it ON again.

NOTE: the "Err" message appears in case of a failed programming operation. In this case push again button if you want to restart the upload again or remove the "HOT-KEY" to abort the operation.

#### 18.2 PROGRAM AN INSTRUMENT BY USING A HOT KEY (DOWNLOAD)

#### Turn OFF the instrument

- Insert a pre-programmed "HOT-KEY" into the 5-PIN receptacle and then turn the Controller 2. ON
- The parameter list of the "HOT-KEY" will be automatically downloaded into the Controller 3. memory. The "doL" message will blink followed a by a flashing "End" label.
- After 10 seconds the instrument will restart working with the new parameters. 4
- 5. Remove the "HOT-KEY".

NOTE: the message "Err" is displayed for failed programming. In this case turn the unit off and then on if you want to restart the download again or remove the "HOT-KEY" to abort the operation

19.	AL	ARI	M SI	GN	AI	LS

Message	Cause	Outputs		
P1 Room probe failure		Compressor output works with Con and CoF		
P2 Evaporator probe failure P3 Third probe failure		Defrost end is timed		
		Outputs unchanged		
P4	Fourth probe failure	Outputs unchanged		
HA	Maximum temperature alarm	Outputs unchanged		
LA	Minimum temperature alarm	Outputs unchanged		
HA2	Condenser high temperature	It depends on the AC2 parameter		

Message	Cause	Outputs
LA2	Condenser low temperature	It depends on the bLL parameter
dA	Door open	Compressor restarts
EA	External alarm	Output unchanged
CA	Serious external alarm (ixF=bAL)	All outputs OFF
rtC	Real time clock parameter error	Output unchanged, defrost follows idF, need to set RTC parameters
rtF	Real time clock malfunctioning	Output unchanged, defrost follows idF

## 19.1 BUZZER MUTING OR ALARM RELAY OUTPUT DEACTIVATION

If tbA=Y, the buzzer and the relay are silenced by pressing any key

If tbA=n, only the buzzer is silenced while the alarm relay is on until the alarm condition recovers

### 19.2 ALARM RECOVERY

Probe alarms "P1", "P2", "P3" and "P4" start some seconds after the fault in the related probe; they automatically stop some seconds after the probe restarts normal operation. Check connections before replacing the probe.

Temperature alarms "HA" and "LA" automatically stop as soon as the temperature returns to normal values

Alarms "EA" and "CA" (with i1F=bAL) recover as soon as the digital input is disabled

- 19.3 OTHER MESSAGES
- Pon Keyboard unlocked
- PoF Keyboard locked
- noP
- In programming mode: no parameter in Pr1. On the display or in dP2, dP3, dP4: the selected probe is not enabled.

### 20. TECHNICAL DATA

Housing: self-extinguishing ABS

Case: frontal 32x74mm; depth 60mm Mounting: panel mounting in a 71x29mm panel cut-out

Protection: IP20

Frontal protection: IP65

Connections: Screw terminal block ≤ 2.5 mm<sup>2</sup> wiring

Power supply: (according to the model) 230Vac ±10%, 50/60Hz; 110Vac ±10%, 50/60Hz Power absorption: 3VA max

Display:

3 digits, red LEDs, 14.2 mm high (CX format)

3 digits, red LEDs, 19 mm high (CH format)

Inputs: Up to 4 NTC, PTC or PT1000 probes

Digital inputs: free voltage contact Frequency output: 30 to 200 Hz, 14Vdc MAX, duty cycle=50% Relay outputs (nominal ratings): oA1: SPST 16(5)A 250Vac

- oA2: SPDT 8(3)A, 250Vac
- oA3: SPST 5(2)A, 250Vac
- oA4: SPST 8(3)A 250Vac

Data storing: on the non-volatile memory (EEPROM)

Internal clock back-up: 24 hours

Kind of action: 1B

Pollution degree: 2

Software class: A


Rated impulsive voltage: 2500V; Overvoltage Category: II Operating temperature: 0 to 55°C (32 to 131°F Storage temperature: -30 to 85°C (-22 to 185°F)

Relative humidity: 20 to 85% (no condensing)

- Measuring and regulation range:
- NTC probe: -40 to 110°C (-40 to 230°F)
- PTC probe: -50 to 150°C (-55 to 302°F)
- PT1000 probe: -100 to 150°C (-148 to 392°F) Resolution: 0.1°C or 1°C or 1°F (selectable)

Accuracy (ambient temp. 25°C): ±0.7°C ±1 digit

### 21. WIRINGS



# Installing and operating instructions

## EMERSON

	AULT SETTING VALUES		
LABEL	Description	VALUE	LEVE
SEt	Regulation Set Point	-20.0	
rtC	RTC menu visualization		Pr1
LS	Minimum Set point	-30.0	Pr2
US	Maximum Set point	10.0	Pr2
Ну	Differential for normal regulation	1.0	Pr1
odS	Outputs delay activation after power on	3	Pr2
AC	Anti-short cycle delay	5	Pr2
AC1	Anti-short cycle delay for second compressor	0	Pr2
MCo	Maximum time with compressor on	0	Pr2
rtr	Percentage for regulation=F(P1; P2) (100=P1; 0=P2)	100	Pr2
CCt	Maximum duration for Pull Down	3.00	Pr1
	Differential for Pull Down (SET+CCS or		
CCS	SET+HES+CCS) Threshold for automatic activation of Pull Down in	-2.0	Pr1
oHt	normal mode (SET+HY+oHt)	10.0	Pr2
Con	Compressor ON time with faulty probe	30	Pr2
CoF	Compressor OFF time with faulty probe	5	Pr2
PbC	Probe selection	ntC	Pr2
ot	Probe P1 calibration	0.0	Pr1
P2P	Probe P2 presence	yes	Pr2
οE	Probe P2 calibration	0.0	Pr2
P3P	Probe P3 presence	no	Pr2
03	Probe P3 calibration	0.0	Pr2
P4P	Probe P4 presence	no	Pr2
04	Probe P4 calibration	0.0	Pr2
		1.0	Pr2
Hy1	Differential for proportional regulation in normal mode		
Fr0	Frequency output value with compressor stopped	0	Pr2
PMi	Minimum compressor speed (in percentage)	20	Pr2
PMA	Maximum compressor speed (in percentage)	100	Pr2
voS	Compressor speed variation (increment) when temperature is increasing	1	Pr2
vo2	Compressor speed variation (decrement) when temperature is decreasing	2	Pr2
vo3	Compressor speed variation (decrement) after any Pull Down	5	Pr2
PdP	Compressor speed during any Pull Down	100	Pr2
t1F	Time with compressor speed at PMI before stopping the compressor	1	Pr2
SPi	Compressor speed (in percentage) in case of any	70	Pr2
Aod	error probe Compressor speed (in percentage) during any defrost	70	Pr2
AoF	(valid if tdf=in) Compressor speed during a pre-defrost phase (valid if	50	Pr2
tHv	tdf=in) Maximum time for compressor speed variation	60	Pr2
-	· · · · · · · · · · · · · · · · · · ·		
tLv	Minimum time for compressor speed variation	20	Pr2
dtC	Temperature sampling time	10	Pr2
tH1	Differential for deadlock control Compressor speed increment during any deadlock	1.0	Pr2
oFS	compressor speed increment during any deadlock condition (in Hz)	1	Pr2
CMn	Continuous mode during normal mode	yes	Pr2
CME	Continuous mode during energy saving mode	yes	Pr2
MnP	Minimum compressor speed for activating lubrication control (valid only for variable speed compressors)	30	Pr2
tMi	Compressor running time below the MnP threshold	01:00	Pr2
tMA	Interval of time with compressor a PMA during lubrication control	1	Pr2
CF	Temperature measurement unit: Celsius; Fahrenheit	°C	Pr1
rES	Temperature resolution: decimal, integer	dE	Pr1
Lod	Probe displayed on the display	P1	Pr1
		00:00	Pr1
dLy	Display temperature delay Visualization percentage=F(P1: P2) (ex: dtr=1 means		
dtr	Visualization percentage=F(P1; P2) (ex: dtr=1 means VALUE=0.01*P1+0.99*P2)	99	Pr1
EdF	Defrost mode	in	Pr2
tdF	Defrost type: electrical heating, hot gas	in	Pr2
dFP	Probe selection for defrost control	P2	Pr2
dtE	Defrost termination temperature	4.0	Pr2
idF	Interval between two consecutives defrost cycles	24	Pr2

Mair	Manimum langth fan defend	45	D-0
MdF	Maximum length for defrost	45	Pr2
dSd	Start defrost delay	0	Pr2
StC	Compressor stop time before starting any defrost	5	Pr2
dFd	Displaying during defrost	it	Pr1
dAd	Delay for display temperature update after any defrost	20	Pr1
Fdt	Draining time	5	Pr2
Hon	Drain heater activated after draining time Fdt (valid if oAx=Het)	00:00	Pr2
dPo	Defrost after power on	no	Pr2
dAF	Defrost delay after Pull Down	3	Pr2
FAP	Probe selection for evaporator fan	P2	Pr2
FSt	Evaporator fan stop temperature	-10.0	Pr2
HyF	Differential for evaporator fan regulator	1.0	Pr2
FnC	Evaporator fan mode operation	O_n	Pr2
Fnd	Evaporator fan delay after defrost	3	Pr2
FCt	Differential of temperature for forced activation of evaporator fan (o=disabled)	0	Pr2
Ft	Evaporator fan controlled during defrost	no	Pr2
Fon	Evaporator fan ON time (with compressor OFF)	0	Pr2
FoF	Evaporator fan OFF time (with compressor OFF)	0	Pr2
FAC	Probe selection for condenser fan	nP	Pr2
St2	Regulation Set Point 2 for condenser fan	35.0	Pr2
Hy2	Differential for Set Point 2 for condenser fan regulator	1.0	Pr2
-		-	
FCC FCo	Condenser fan mode operation	0_n 0	Pr2 Pr2
	Condenser fan on after switching off the compressor	-	
ACH	Kind of action for auxiliary regulator	CL	Pr2
SAA	Set point for auxiliary regulator	0.0	Pr2
SHy	Differential for auxiliary regulator	1.0	Pr2
ArP	Probe selection for auxiliary regulator	nP	Pr2
Sdd	Auxiliary regulator disabled during any defrost	no	Pr2
ALP	Probe selection for temperature alarms	P1	Pr1
ALC	Temperature alarms configuration: relative, absolute	rE	Pr1
ALU	Maximum temperature alarm	8.0	Pr1
ALL	Minimum temperature alarm	7.0	Pr1
AFH	Temperature alarm recovery differential	1.0	Pr1
ALd	Temperature alarm delay	10	Pr1
dAo	Temperature alarm delay after power-on	24.00	Pr1
AP2	Probe selection for second temperature alarms	nP	Pr2
AL2	Second low temperature alarm	-40.0	Pr2
AU2	Second high temperature alarm	110.0	Pr2
AH2	Differential for second temperature alarm recovery	1.0	Pr2
Ad2	Second temperature alarm delay	5	Pr2
dA2	Delay for second temperature alarm after power-on	01:00	Pr2
bLL	Compressor off due to second low temperature alarm	no	Pr2
AC2	Compressor off due to second high temperature alarm	yes	Pr2
SAF	Differential for anti-freezing control	5.0	Pr2
tbA	Alarm relay switched off by pushing any key	yes	Pr2
oA1	Relay output oA1 configuration	LiG	Pr2
0A2	Relay output oA2 configuration	dEF	Pr2
0A2	Relay output oA3 configuration	Fan	Pr2
0A3 0A4	Relay output oA4 configuration	ALr	Pr2
oA4 oAn	Analogue output configuration	FrE	Pr2
AOP	Alarm relay polarity	CL	Pr2
i1P	Digital input 1 polarity	CL	Pr1
i1F	Digital input 1 configuration	dor	Pr1
did	Digital inputs 1 alarm delay	1	Pr1
nPS	Number of pressure alarm switch before stopping the regulation (Lock alarm)	5	Pr1
	Compressor and fan status after door opening	F-C	Pr1
OdC	Compressor and ran status after door opening	10	
OdC rrd	Regulation restart after open door alarm	yes	Pr1

# Installing and operating instructions

LdE	Energy saving mode controls the lights (lights off	1/05	Pr1
Hur	when energy saving goes active)	yes	Pr1
Min	Minutes		Pr1
dAY	Day of the week		Pr1
dyM	Day of the month		Pr1
Mon	Month		Pr1
yAr	Year		Pr1
Hd1	First day of week end	Sat	Pr2
Hd2	Second day of week end	Sun	Pr2
il F	Working days Energy saving starting time	00:00	Pr2
dLE	Working days Energy saving duration	00:00	Pr2
iSE	Holyday Energy saving starting time	00:00	Pr2
dSE	Holyday Energy saving duration	00:00	Pr2
dd1	Sunday defrost	no	Pr2
dd2	Monday defrost	no	Pr2
dd3	Tuesday defrost	no	Pr2
dd4	Wednesday defrost	no	Pr2
dd5	Thursday defrost	no	Pr2
dd6	Friday defrost	no	Pr2
dd7	Saturday defrost	no	Pr2
Ld1	1st defrost starting time	nu	Pr2
Ld1	2nd defrost starting time	nu	Pr2
Ld2	3rd defrost starting time	nu	Pr2
Ld4	4th defrost starting time	nu	Pr2
Ld5	5th defrost starting time	nu	Pr2
Ld6	6th defrost starting time	nu	Pr2
Adr	Serial address	1	Pr2
bAU	Baud rate selection for serial port	9.6	Pr2
onC	ONOFF button configuration	ES	Pr2
on2	ONOFF button timed (3sec) configuration	oFF	Pr2
LG2	Light button timed (3sec) configuration	nU	Pr2
dn2	Down button timed (3sec) configuration	Lnt	Pr2
dP1	Probe P1 value visualization	Lin	Pr1
dP2	Probe P2 value visualization		Pr1
dP3	Probe P3 value visualization		Pr1
dP4	Probe P4 value visualization		Pr1
SPd	Instantaneous compressor speed (in Hz)		Pr1
rSE	Real regulation Set Point		Pr1
rEL	Firmware release		Pr1
Ptb	Parameter map code	1	Pr1
SEt_nt	Regulation Set Point	3.0	
rtC_nt	RTC menu visualization		Pr1
LS nt	Minimum Set point	-50.0	Pr2
US_nt	Maximum Set point	50.0	Pr2
Hy_nt	Differential for normal regulation	2.0	Pr1
odS_nt	Outputs delay activation after power on	1	Pr2
AC_nt	Anti-short cycle delay	1	Pr2
AC1 nt	Anti-short cycle delay for second compressor	5	Pr2
MCo_nt	Maximum time with compressor on	0	Pr2
rtr_nt	Percentage for regulation=F(P1; P2) (100=P1; 0=P2)	100	Pr2
CCt_nt	Maximum duration for Pull Down	3.00	Pr1
CCS_nt	Differential for Pull Down (SET+CCS or	2.0	Pr1
oHt_nt	SET+HES+CCS) Threshold for automatic activation of Pull Down in	10.0	Pr2
Con_nt	normal mode (SET+HY+oHt) Compressor ON time with faulty probe	10.0	Pr2
CoF_nt	Compressor OFF time with faulty probe	5	Pr2
PbC_nt	Probe selection	ntC	Pr2
ot_nt	Probe P1 calibration	0.0	Pr2
01_111	Probe P2 presence	0.0	Pr1 Pr2

set.ntProbe P2 calibration0.0P2P3P_ntProbe P3 presencenoP/2s3_ntProbe P3 presencenoP/2s4_ntProbe P4 calibration0.0P/2P4P_ntDifferential for proportional regulation in normal mode3.0P/2P4T_ntDifferential for proportional regulation in normal mode3.0P/2PM_ntMinimum compressor speed (in percentage)100P/2PMA_ntMaximum compressor speed (in percentage)100P/2vo3_ntParification (increment) when1P/2vo3_ntParification (increment) when2P/2vo3_ntParification (increment) when2P/2vo3_ntParification (increment) when100P/2vo3_ntParification (increment) when100P/2vo3_ntParification (increment) after any5P/2Add_ntCompressor speed (in percentage) in case of any error proba70P/2Add_ntMinimum lime for compressor speed variation60P/2HV_ntMaximum lime for compressor speed variation100P/2CML_ntContinuous mode during any deadlock1P/2CML_ntContinuous mode during normal modeyesP/2CML_ntContinuous mode during normal modeyesP/2CML_ntContinuous mode during normal modeyesP/2CML_ntContinuous mode during normal modeyesP/2CML_ntContinuous mode d				
AutomAutomAutom63.ntProbe P3 calibration0.0P72P4P.ntProbe P4 calibration0.0P72Hy1.ntDifferential for proportional regulation in normal mode3.0P72Fr0.ntFrequency oudput value with compressor stopped2.0P72PML.ntMinimum compressor speed (in percentage)2.0P72voS.ntEmperature is increasing1P72voS.ntCompressor speed valiation (increment) when2P72voS.ntCompressor speed (in percentage) increment of the compressor8.0P72Adc.ntCyrid (frefin)6.0P72Adc.ntCompressor speed (in percentage) during any defost8.0P72Adc.ntCompressor speed (in percentage) during any defost8.0P72Adc.ntCompressor speed (in percentage) during any defost9.0P72Adc.ntCompressor speed valiation0.0P72It.v.ntMaximum time for compressor speed valiation9.0P72Gr.ntTemperature measurement during any deadlock1P72GFS.ntCompressor speed increment during any deadlock1P72GFS.ntCompressor speed increment during any d	oE_nt	Probe P2 calibration	0.0	Pr2
P4P_ntProbe P4 presencenoP/204_ntProbe P4 calibration0.0Pr2Hy1_ntDifferential for proportional regulation in normal mode3.0Pr2Fr0_ntFrequency output value with compressor stopped2.0Pr2PM_ntMinimum compressor speed (in percentage)100Pr2vo3_ntCompressor speed variation (increment) when2Pr2vo3_ntCompressor speed variation (decrement) when2Pr2vo3_ntCompressor speed variation (decrement) when2Pr2vo3_ntCompressor speed variation (decrement) after any error probe5Pr2PdP_ntCompressor speed variation (decrement) after any error probe60Pr2Aof_ntCompressor speed (in percentage) in case of any error probe70Pr2Aof_ntCompressor speed during a pre-defort phase (valid) if doin procentage) during any defoot80Pr2dbf_ntConfinescor speed during a pre-defort phase (valid) if doin pre-sor speed during a pre-defort phase (valid) if doin Pr2972tHv_ntMinimum time for compressor speed variation20Pr2dbf_ntConfinuous mode during normal modeyesPr2dbf_ntConfinuous mode during normal	P3P_nt	Probe P3 presence	no	Pr2
P4P_ntProbe P4 presencenoP/2od_ntProbe P4 calibration0.0P/2Hy1_ntDifferential for proportional regulation in normal mode3.0P/2Ff0_ntFrequency output value with compressor stopped200P/2PM_ntMinimum compressor speed (in percentage)100P/2vo3_ntCompressor speed variation (increment) when2P/2vo3_ntCompressor speed variation (idcrement) when2P/2vo3_ntCompressor speed variation (idcrement) when100P/2tf1_ntTime with compressor speed a PMI before stopping1P/2SP1_ntCompressor speed variation (idcrement) after any error probed (in percentage) in case of any error probed (in percentage) in case of any error probed (in percentage) in case of any error probed (in percentage) address these (valid) if60P/2P/2P/2P/2Aof_ntCompressor speed during a pre-deforts phase (valid) if60P/2tf1_ntDifferential for deadlock control1.0P/2dtC_ntTemperature sampling time10P/2tf1_ntContinuous mode during norge any defored90P/2MnP_ntCompressor speed of satisticing lubication oundition (in Hz)P/2CML_ntContinuous mode during normal modeyesP/2dtC_ntTemperature delay0.0P/2dtf_ntContinuous mode during normal modeyesP/2dtf_ntCompressor speed repressor speed repressor3.0	o3 nt	Probe P3 calibration	0.0	Pr2
of.ntProbe P4 calibration0.0P/2Hy1_ntDifferential for proportional regulation in normal mode3.0P/2Fr0_ntFrequency output value with compressor speed (in percentage)200P/2PMA_ntMaximum compressor speed (in percentage)100P/2vo3_ntEmpressor speed variation (increment) when2P/2vo3_ntEmpressor speed variation (increment) when2P/2vo3_ntEmpressor speed variation (increment) when2P/2vo3_ntEmpressor speed variation (increment) when100P/2tifF_ntTrme with compressor speed at PMI before stopping1P/2SPI_intCompressor speed during any defost80P/2Aod_ntCompressor speed during any defost phase (valid) if60P/2tHv_ntMaximum time for compressor speed variation20P/2tHv_ntMaximum time for compressor speed variation10P/2tHv_ntMaximum time for compressor speed variation10P/2tHv_ntCompressor speed increment during any deadock1P/2tMr_ntCompressor speed increm	-			Pr2
Hy1_ntDifferential for proportional regulation in normal mode3.0P/2Fr0_ntFrequency output value with compressor speed (in percentage)20P/2PMA_ntMaximum compressor speed (in percentage)100P/2voS_ntCompressor speed (unifor comment) when1P/2voS_ntCompressor speed variation (decrement) when2P/2vo3_ntCompressor speed variation (decrement) when2P/2vo3_ntFormpressor speed variation (decrement) after any5P/2PHP_ntCompressor speed (in percentage) in case of any error probe70P/2Aof_ntCompressor speed (in percentage) during any defrost (valid fatterin)80P/2Aof_ntCompressor speed (in percentage) during any defrost (valid fatterin)80P/2Hth_ntMaximum time for compressor speed variation60P/2Ltv_ntMinimum time for compressor speed variation10P/2CMT_ntCompressor speed luring any dedlock1P/2GFS_ntCompressor speed increment during any dedlock1P/2CML_ntContinuous mode during normal modeyesP/2CML_ntContinuous mode during normal modeyesP/2CML_ntCompressor speed in crement during any dealock1P/2CML_ntCompressor speed increment during any dealock1P/2CML_ntCompressor speed increment during any dealock1P/2CML_ntCompressor speed increment during any defrost<				Pr2
Fr6.ntFrequency output value with compressor stopped20P/2PMA_ntMaximum compressor speed (in percentage)100P/2voS.ntCompressor speed variation (increment) when1P/2voZ.ntCompressor speed variation (increment) when2P/2PPd_ntCompressor speed variation (increment) when1P/2voS.ntPr0Pr0Pr2PdP_ntCompressor speed variation (increment) when1P/2SPL_ntEmprestor speed variation (increment) after any5P/2Add_ntCompressor speed (in percentage) in case of any error probe70P/2Aof_ntCompressor speed (in percentage) in case of any error probe70P/2Adf_ntCompressor speed (in percentage) in case of any error probe70P/2Hu_ntMaximum time for compressor speed variation60P/2Ht_ntMinimum time for compressor speed variation20P/2GE_ntContinuous mode during normal modeyesP/2GM_ntContinuous mode during normal modeyesP/2GM_n				Pr2
PMI.ntMinimum compressor speed (in percentage)20P/2PMA_ntMaximum compressor speed (in percentage)100P/2voS_ntCompressor speed variation (increment) when temperature is increasing compressor speed variation (ideorement) after any to price seasing5P/2voJ_ntCompressor speed variation (ideorement) after any to price seasing tem with compressor speed variation (ideorement) after any error probe error pro	• -			
PMA.ntMaximum compressor speed (in percentage)100P/2voS.ntCompressor speed variation (increment) when termersture is increasing compressor speed variation (idecrement) after any to any Compressor speed variation (idecrement) after any to any Compressor speed variation (idecrement) after any to price SPLP/2PdP.ntCompressor speed variation (idecrement) after any error probe compressor speed variation (idecrement) after any error probe error probe error probe100P/2Aof.ntCompressor speed (in percentage) in case of any error probe error probe error probe000P/2Aof.ntCompressor speed variation60P/2Aof.ntCompressor speed variation20P/2dtf.ntIthin unit time for compressor speed variation20P/2dtf.ntTemperature sampling time10P/2tHv.ntMinimum time for compressor speed variation20P/2dtf.ntCompressor speed increment during any dedock1P/2GFs.ntCompressor speed increment during any deadock1P/2CMm_ntContinuous mode during normal modeyesP/2Mn P.ntContinuous mode during normal modeyesP/2Mn P.ntCompressor speed or advating lubrication30P/2Mnt.ntCompressor speed or advating lubrication30P/2Mnt.ntCompressor speed or advating lubrication30P/2Mnt.ntCompressor speed or advating lubrication30P/2Mnt.ntCompre				
voS.ntCompressor speed variation (increment) when temperature is foresaing compressor speed variation (decrement) after any perature bit of cereasing temperature is decreasing1Pr2 Pr2Vo3.ntPdP_ntCompressor speed variation (decrement) after any perature is decreasing temperature is decreas	-		-	
vo2.nttemperature is increasing temperature is decreasing temperature is decreasing temperature is decreasing to compressor speed during any Pull DownPV2PdP_ntCompressor speed during any Pull Down100PV2tTF_ntTime with compressor speed at PMI before stopping temperature and the compressor temperature and the compressor speed during any defined temperature and the compressor speed during any redeforst phase (valid if temperature and the compressor speed during any redeforst phase (valid if temperature and the compressor speed variation80Pv2Aof_ntCompressor speed during a pre-defrost phase (valid if temperature and the compressor speed variation60Pv2tHu_ntMaximum time for compressor speed variation20Pv2tHu_ntDifferential for deadlock control1.0Pv2tH_ntDifferential for deadlock control1.0Pv2CMn_ntContinuous mode during normal modeyesPv2CMn_ntContinuous mode during normal modeyesPv2CMn_ntCompressor speed for activating lubrication control (valid only for variable speed compressors)30Pv2tM_ntInterval of time with compressor a PMA during lubrication controlPv1Pv1tdf_ntProbe displayed on the displayPv1Pv1dff_ntDefrost type: electrical heating, hot gasinPv2tGF_ntTemperature resolution: decimal, integer80Pv2dff_ntDefrost type: electrical heating, hot gasinPv2dff_ntDefrost type: electrical heating		1 1 (1 6)		
vol_nttemperature is decreasing2Prizvol_ntCompressor speed variation (decrement) after any Pull Down5PrizPdP_ntCompressor speed at PMI before stopping the compressor speed at PMI before stopping the compressor speed (in percentage) in case of any more probe for problem properties of the percentage) during any defrost dati fit fielin.80PrizAod_ntCompressor speed (in percentage) during any defrost dati fit fielin.80PrizAof_ntCompressor speed during a pre-defrost phase (valid if fielin).60PrizHv_ntMaximum time for compressor speed variation60PrizdtC_ntTemperature sampling time10PrizHf_ntDifferential for deadlock control1.0PrizoFS_ntContinuous mode during normal modeyesPrizCME_ntContinuous mode during energy saving modeyesPrizMnP_ntContinuous mode during energy saving modeyesPrizMn_ntContinuous mode during energy saving modeyesPrizCME_ntContinuous mode during energy saving modeyesPrizMn_ntCompressor speed for activating lubrication control (ulid only for variable speed compressors)30PrizfdF_ntTemperature measurement unit: Celsius; Fahrenheit°CPri1Ld_ntProbe displayed on the displayP1Pri1duf_ntValue=00.01P14.039P2)P2Prizdef_ntDefrost modeinPrizdfF_ntDefrost memo		temperature is increasing Compressor speed variation (decrement) when		
NOINPull DownInternationalJoinPrizePdP_ntCompressor speed during any Pull Down100PrizeSPi_ntTime with compressor speed at PMI before stopping error probe1PrizeAd_ntCompressor speed (in percentage) uning any defrost (wald withon)80PrizeAd_ntCompressor speed uning any defrost (wald withon)60PrizeHu_ntMaximum time for compressor speed variation00PrizedtC_ntTemperature sampling time10PrizedtG_ntCompressor speed increment during any deallock 		temperature is decreasing	_	
IfF_ntTime with compressor speed at PMI before stopping the compressor speed (in percentage) in case of any error prossor error prossor speed variationPr2Aod_nt error prossor speed variation60Pr2Abf_ntCompressor speed variation60Pr2Itv_ntMaximum time for compressor speed variation20Pr2dtC_ntTemperature sampling time10Pr2dtf_ntDifferential for deadlock control1.0Pr2GM_ntContinuous mode during normal modeyesPr2CME_ntContinuous mode during normal modeyesPr2CME_ntContinuous mode during normal modeyesPr2CME_ntContinuous mode during normal modeyesPr2CME_ntContinuous mode during normal modeyesPr2CME_ntCompressor running time below the MP threshold00:00Pr2IM_ntInferval of time who compressor a PMA during lubrication control0Pr2CF_ntTemperature resolution: decimal, integerdEPr1Ld_ntVALUE=0:01*P11:03*P2 (sec. dtr=1 means VALUE=0:01*P11:03*P2) (sec. dtr=1 means VALUE=0:01		Pull Down	-	
It is the compressor speed (in percentage) in case of any error probe70Pri2Aod_ntCompressor speed (in percentage) during any defrost (valid it defin)80Pri2AoF_ntCompressor speed during any re-defrost phase (valid it (td=in)60Pri2Ltv_ntMaximum time for compressor speed variation20Pri2Ltv_ntMinimum time for compressor speed variation10Pri2Ltv_ntMinimum time for compressor speed variation20Pri2CMC_ntTemperature sampling time10Pri2CMC_ntContinuous mode during normal modeyesPri2ORF_ntContinuous mode during normal modeyesPri2CME_ntContinuous mode during energy saving modeyesPri2MnP_ntContinuous mode during energy saving modeyesPri2CME_ntCompressor running time below the MnP threshold00:00Pri2LtM_ntInterval of time with compressor a PMA during lubrication control00:00Pri2CF_ntTemperature resolution: decimal, integerdEPri1Ld_ntProbe displayed on the displayP1Pri1Ld_ntValue2-00*P1*0.99*20(ex. dtr=1 means99Pri2dFf_ntDefrost termination temperature80.0Pri2CF_ntTemperature delay00:00Pri2Pri2dff_ntDefrost termination temperature80.0Pri2dff_ntDefrost termination temperature80.0Pri2dff_ntDefros				
And_ntProjectProductAod_ntCompressor speed (in percentage) during any defrost (valid if defin)80Pr2AoF_ntCompressor speed during a pre-defrost phase (valid if defin)60Pr2thv_ntMaximum time for compressor speed variation60Pr2ttv_ntMinimum time for compressor speed variation20Pr2dtC_ntTemperature sampling time10Pr2dtC_ntTemperature sampling time10Pr2oFS_ntCompressor speed increment during any deadlock condition (in Hz)1Pr2CMn_ntContinuous mode during energy saving modeyesPr2MnP_ntContinuous mode during energy saving modeyesPr2MnP_ntContinuous mode during energy saving modeyesPr2MnP_ntContinuous mode during energy saving modeyesPr2MnP_ntContral (valid only for variable speed compressors)30Pr2ttM_ntCompressor speed for activating lubrication orothol (valid only for variable speed compressors)30Pr2ttM_ntInterval of time with compressor a PMA during lubrication control0Pr2ttM_ntInterval of time with compressor a PMA during lubrication control0Pr2tdF_ntProbe displayed on the displayP1Pr1tdL_ntVALUE=0.01P+10.93PF2)(ex: dt=1 means g.g.99Pr1tdF_ntDefost throid elay0Pr2Pr2tdF_ntDefost torot definest controlP2		the compressor		
Ave_init(valid iffdefin)out		error probe		
HUT_INIdeaHousingHousingHV_ntMaximum time for compressor speed variation60Pr2LV_ntMinimum time for compressor speed variation20Pr2dtC_ntTemperature sampling time10Pr2H1_ntDifferential for deadlock control1.0Pr2GFS_ntCompressor speed increment during any deadlock1Pr2CME_ntContinuous mode during normal modeyesPr2CME_ntContinuous mode during normal modeyesPr2CME_ntContinuous mode during normal modeyesPr2MnP_ntControl (valid only for variable speed compressors)30Pr2tMA_ntInterval of time with compressor a PMA during0Pr2tMA_ntInterval of time with compressor a PMA during0Pr2tMA_ntUniversition controlCPr1dfS_ntTemperature resolution: decimal, integerdEPr1dd_yntDisplay temperature delay00:00Pr1df_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means99Pr1dfF_ntDefrost type: electrical heating, hot gasinPr2dfF_ntDefrost type: electrical heating, hot gasinPr2dfF_ntDefrost type: electrical heating any defrost2Pr2dff_ntInterval between two consecutives defrost cycles8Pr2dff_ntInterval between two consecutives defrost cycles8Pr2dff_ntDelrost after power onno<		(valid if tdf=in)		
ILv_ntMinimum time for compressor speed variation20P/2dtC_ntTemperature sampling time10P/2H1_ntDifferential for deadlock control1.0P/2oFS_ntCompressor speed increment during any deadlock1P/2CMn_ntContinuous mode during normal modeyesP/2CML_ntContinuous mode during normal modeyesP/2CML_ntContinuous mode during energy saving modeyesP/2MnP_ntComtinuous mode during energy saving modeyesP/2MnL_ntCompressor speed for activating lubrication control (valid only for variable speed compressors)30P/2IM_A_ntInterval of time with compressor a PIMA during lubrication control0P/2CF_ntTemperature measurement unit: Celsius; Fahrenheit°CP/1Ld_ntPise displayed on the displayP1P/1dLy_ntDisplay temperature delay00:00P/1dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means99P/1dFP_ntProbe displayed on the displayDP/2P/2dfE_ntDefrost type: electrical heating, hot gasinP/2P/2dfF_ntInterval between two consecutives defrost cycles8P/2dfF_ntInterval between two consecutives defrost cycles8P/2dfG_ntDisplaying during defrost10P/1dfA_ntDelaying during defrost10P/1dfA_ntDelaying during defrost10<	AoF_nt		60	Pr2
dtC_ntTemperature sampling time10Pr2tH1_ntDifferential for deadlock control1.0Pr2oFS_ntCompressor speed increment during any deadlock1Pr2CMn_ntContinuous mode during normal modeyesPr2CME_ntContinuous mode during energy saving modeyesPr2CME_ntContinuous mode during energy saving modeyesPr2CME_ntContinuous mode during energy saving modeyesPr2CME_ntComtinuous mode during energy saving modeyesPr2tMi_ntCompressor running time below the MnP threshold00:00Pr2tMA_ntInterval of time with compressor a PMA during lubrication control0Pr2CF_ntTemperature neasurement unit: Celsius; Fahrenheit°CPr1Lod_ntProbe displayed on the displayP1Pr1dLy_ntDisplay temperature delay00:00Pr1dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means99Pr1dtF_ntDefrost modeinPr2dtF_ntDefrost torpic electrical heating, hot gasinPr2dtG_ntDefrost termination temperature8.0Pr2dtG_ntStart defrost delay0Pr2dtG_ntStart defrost delay0Pr2dtG_ntDisplaying during defrost10Pr1dtG_ntDefrost torperature update after any defrost10Pr1dtG_ntDelay for display temperature update after any defrost10<	tHv_nt	· · · · · · · · · · · · · · · · · · ·		
HH1_ntDifferential for deadlock control1.0Pr2oFS_ntCompressor speed increment during any deadlock1Pr2CMn_ntContinuous mode during normal modeyesPr2CME_ntContinuous mode during energy saving modeyesPr2CME_ntContinuous mode during energy saving modeyesPr2CME_ntContinuous mode during energy saving modeyesPr2IM_ntMinimum compressor speed for activating lubrication control (valid only for variable speed compressors)30Pr2IM_ntInterval of time with compressor a PMA during0Pr2CF_ntTemperature measurement unit: Celsius; Fahrenheit°CPr1Lod_ntProbe displayed on the displayP1Pr1dLy_ntDisplay temperature delay00:00Pr1dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means VALUE=0.01*P1-0.99*P2)99Pr1dtF_ntDefrost modeinPr2dtF_ntDefrost termination temperature8.0Pr2dtF_ntInterval between two consecutives defrost cycles8Pr2ddF_ntInterval defrost delay0Pr2dtG_ntDisplaying during defrost15Pr2ddf_ntDefrost delay after fraining time Fdt (valid if 00:00Pr2ddf_ntDelay for display temperature update after any defrost10Pr1ddf_ntDefrost delay after Pull Down1Pr2dA_ntDefrost delay after Pull Down1Pr2 </th <th></th> <td>Minimum time for compressor speed variation</td> <td></td> <td></td>		Minimum time for compressor speed variation		
oFS_nt         Compressor speed increment during any deadlock condition (in Hz)         1         Pr2           CMn_nt         Continuous mode during normal mode         yes         Pr2           CME_nt         Continuous mode during energy saving mode         yes         Pr2           MnP_nt         Minimum compressor speed for activating lubrication control (valid only for variable speed compressors)         30         Pr2           tMi_nt         Compressor running time below the MnP threshold         00:00         Pr2           tMA_nt         Interval of time with compressor a PMA during         0         Pr2           CF_nt         Temperature measurement unit: Celsius; Fahrenheit         °C         Pr1           Lod_nt         Probe displayed on the display         P1         Pr1           dtr_nt         Visualization percentage=F(P1; P2) (ex: dtr=1 means VALUE=0.01*P1*0.99*P2)         99         Pr1           dtr_nt         Defrost torpic electrical heating, hot gas         in         Pr2           dtF_nt         Defrost tremination temperature         8.0         Pr2           dtF_nt         Interval between two consecutives defrost cycles         8         Pr2           dtGf_nt         Defrost termination temperature defa after any defrost         10         Pr1           ddf_nt         Delay fo	dtC_nt	Temperature sampling time	10	Pr2
C 0_mitcondition (in Hz)FileCMn_ntContinuous mode during normal modeyesPr2CME_ntContinuous mode during energy saving modeyesPr2MnP_ntMinimum compressor speed for activating lubrication control (valid only for variable speed compressors)30Pr2tMi_ntCompressor running time below the MnP threshold00:00Pr2tMA_ntInterval of time with compressor a PMA during ubrication control0Pr2CF_ntTemperature measurement unit: Celsius; Fahrenheit°CPr1tLod_ntProbe displayed on the displayP1Pr1dLy_ntDisplay temperature delay00:00Pr1dtr_ntVisualization percentage=f(P1; P2) (ex: dtr=1 means99Pr1dtF_ntDefrost modeinPr2dtF_ntDefrost modeinPr2dtF_ntDefrost modeinPr2dtG_ntStart defrost delay0Pr2ddf_ntInterval between two consecutives defrost cycles8Pr2ddf_ntDisplaying during defrost15Pr2ddf_ntDefrost topical delay0Pr1ddd_ntDelay for display temperature update after any defrost10Pr1ddf_ntDefrost delay defrost10Pr1ddf_ntDefrost delay defrost10Pr1ddf_ntDefrost delay after Pull Down1Pr2ddf_ntDefrost delay after Pull Down1Pr2fdf_ntDefrost delay afte	tH1_nt		1.0	Pr2
CME_ntContinuous mode during energy saving modeyesPr2MnP_ntMinimum compressor speed for activating lubrication30Pr2tMi_ntCompressor running time below the MnP threshold00:00Pr2tMA_ntInterval of time with compressor a PMA during0Pr2CF_ntTemperature measurement unit: Celsius; Fahrenheit°CPr1rES_ntTemperature resolution: decimal, integerdEPr1Lod_ntProbe displayed on the displayP1Pr1dLy_ntDisplay temperature delay00:00Pr1dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means99Pr1EdF_ntDefrost modeinPr2dtF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost termination temperature8.0Pr2dtG_ntDisplaying during defrost controlP2Pr2dtG_ntDisplaying during defrostitPr1dtd_ntDelay for display temperature update after any defrost10Pr1dtd_ntDelay for display temperature update after any defrost10Pr12dtG_ntDrain heater activated after draining time Fdt (valid if 00:000Pr2dtA_ntDefrost delay after Pull Down1Pr2ftot_nt <td< th=""><th>oFS_nt</th><td>Compressor speed increment during any deadlock condition (in Hz)</td><td>1</td><td>Pr2</td></td<>	oFS_nt	Compressor speed increment during any deadlock condition (in Hz)	1	Pr2
MnP_ntMinimum compressor speed for activating lubrication control (valid only for variable speed compressors)30Pr2tMi_ntCompressor running time below the MnP threshold00:00Pr2tMA_ntInterval of time with compressor a PMA during0Pr12CF_ntTemperature measurement unit: Celsius; Fahrenheit°CPr1tES_ntTemperature resolution: decimal, integerdEPr1Lod_ntProbe displayed on the displayP1Pr1dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means99Pr1dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means99Pr12dtF_ntDefrost modeinPr22dtF_ntDefrost modeinPr22dtF_ntDefrost termination temperature8.0Pr22dtF_ntInterval between two consecutives defrost cycles8Pr22ddf_ntDelay or display temperature update after any defrost10Pr12ddf_ntDisplaying during defrost15Pr22dfd_ntDelay or display temperature update after any defrost10Pr12ddd_ntDelay or display temperature update after any defrost10Pr12dfd_ntDefrost after power onnoPr12dfd_ntDefrost delay after draining time Fdt (valid if 0Ax=Het)00:00Pr22dfd_ntDefrost delay after draining time Fdt (valid if 0Ax=Het)00:00Pr22dfd_ntDefrost delay after defrost5Pr22dfd_nt <th< th=""><th>CMn_nt</th><td>Continuous mode during normal mode</td><td>yes</td><td>Pr2</td></th<>	CMn_nt	Continuous mode during normal mode	yes	Pr2
min_intcontrol (valid only for variable speed compressors)30F12tMi_ntCompressor running time below the MnP threshold00:00Pr2tMA_ntInterval of time with compressor a PMA during0Pr2CF_ntTemperature measurement unit: Celsius; Fahrenheit°CPr1tES_ntTemperature resolution: decimal, integerdEPr1dLod_ntProbe displayed on the displayP1Pr1dLy_ntDisplay temperature delay00:00Pr1dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means99Pr1dtf_ntDefrost modeinPr2dtF_ntDefrost tremination temperature8.0Pr2dtF_ntDefrost termination temperature8.0Pr2dtG_ntDefrost termination temperature8.0Pr2ddf_ntInterval between two consecutives defrost cycles8Pr2ddf_ntDisplaying during defrost15Pr2ddf_ntDisplaying during defrost10Pr1dAd_ntDelay for display temperature update after any defrost10Pr1dAd_ntDelay of display temperature update after any defrost10Pr1dAd_ntDefrost delay after draining time Fdt (valid if oAx=Het)00:00Pr2dF1_ntDraining time5Pr2Pr2dF2_ntDefrost delay after defrost10Pr1dF4_ntDefrost after power onnoPr12dF4_ntDefrost after power onnoPr2<	CME_nt		yes	Pr2
tMA_ntInterval of time with compressor a PMA during lubrication control0Pr2CF_ntTemperature measurement unit: Celsius; Fahrenheit°CPr1rES_ntTemperature resolution: decimal, integerdEPr1Lod_ntProbe displayed on the display00:00Pr1dLy_ntDisplay temperature delay00:00Pr1dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means99Pr1EdF_ntDefrost modeinPr2dtF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost termination temperature8.0Pr2dtF_ntDefrost termination temperature8.0Pr2ddf_ntDisplaying during defrost15Pr2dSd_ntStart defrost delay0Pr1StC_ntCompressor stop time before starting any defrost2Pr2dFd_ntDraining time5Pr2dAd_ntDefrost delay after Pull Down1Pr2dAF_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2fAP_ntDifferential for evaporator fan regulator1.0Pr2frod_ntDefrost fan delay after defrost5Pr2for_ntEvaporator fan node operationC_nPr2fAf_ntDefrost delay after Pull Down<	MnP_nt		30	Pr2
Internal Induction controlInternal In	tMi_nt		00:00	Pr2
rES_ntTemperature resolution: decimal, integerdEPr1Lod_ntProbe displayed on the displayP1Pr1dLy_ntDisplay temperature delay00:00Pr1dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means99Pr1EdF_ntDefrost modeinPr2tdF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost type: electrical heating, hot gas8.0Pr2idF_ntDefrost termination temperature8.0Pr2idF_ntInterval between two consecutives defrost cycles8Pr2ddf_ntDisplaying during defrost15Pr2ddd_ntStart defrost delay0Pr2stC_ntCompressor stop time before starting any defrost2Pr2dd_ntDisplaying during defrostitPr1dd_ntDefrost delay defrost10Pr1fdt_ntDrain heater activated after draining time Fdt (valid if 00:0000:00Pr2dAf_ntDefrost delay after Pull Down1Pr2fAP_ntProbe selection for evaporator fanP2Pr2fFt_ntDifferential for evaporator fan regulator1.0Pr1fAf_ntDefrost delay after Pull Down1Pr2fFt_ntEvaporator fan stop temperature2.0Pr2fFt_ntDifferential for evaporator fan regulator1.0Pr2fFt_ntEvaporator	tMA_nt		0	Pr2
Lod_ntProbe displayed on the displayP1Pr1dLy_ntDisplay temperature delay00:00Pr1dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means99Pr1dtr_ntDefrost modeinPr2tdF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost termination temperature8.0Pr2idF_ntInterval between two consecutives defrost cycles8Pr2ddf_ntInterval between two consecutives defrost cycles8Pr2ddd_ntStart defrost delay0Pr2dfd_ntStart defrost delay0Pr2dfd_ntDisplaying during defrostitPr1dAd_ntDelay for display temperature update after any defrost10Pr1dfo_ntDrain heater activated after draining time Fdt (valid if o0:00Pr2dfo_ntDefrost after power onnoPr2dAF_ntDefrost delay after Pull Down1Pr2FSt_ntEvaporator fan stop temperature2.0Pr2FSt_ntEvaporator fan mode operationC_nPr2Frd_ntDifferential for evaporator fan regulator1.0Pr2Frd_ntEvaporator fan delay after defrost5Pr2Fot_ntEvaporator fan controlled during defrost10Pr2Ff_ntEvaporator fan node o	CF_nt	Temperature measurement unit: Celsius; Fahrenheit	°C	Pr1
dLy_ntDisplay temperature delay00:00Pr1dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means99Pr1EdF_ntDefrost modeinPr2tdF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost termination temperature8.0Pr2idF_ntInterval between two consecutives defrost cycles8Pr2ddf_ntMaximum length for defrost15Pr2dSd_ntStart defrost delay0Pr2dfd_ntDisplaying during defrostitPr1dAd_ntDelay for display temperature update after any defrost10Pr1dAd_ntDefrost after power onnoPr2dAf_ntDefrost after power onnoPr2dAf_ntDefrost after power onnoPr2dAf_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2Ff_ntDifferential for evaporator fan regulator1.0Pr2Ft_ntEvaporator fan controlled during defrost5Pr2Ft_ntEvaporator fan ON time (with compressor OFF)0Pr2Ft_ntEvaporator fan OFF time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OF	rES_nt	Temperature resolution: decimal, integer	dE	Pr1
dtr_ntVisualization percentage=F(P1; P2) (ex: dtr=1 means VALUE=0.01*P1+0.99*P2)99Pr1EdF_ntDefrost modeinPr2tdF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntDefrost termination temperature8.0Pr2idF_ntInterval between two consecutives defrost cycles8Pr2ddf_ntMaximum length for defrost15Pr2dSd_ntStart defrost delay0Pr2dfd_ntDisplaying during defrostitPr1dAd_ntDelay for display temperature update after any defrost10Pr1dAd_ntDelay for display temperature update after any defrost10Pr2dAd_ntDefrost after power onnoPr2Pr2dAF_ntDefrost delay after Pull Down1Pr2Pr2dAF_ntDefrost delay after Pull Down1Pr2Pr2fAP_ntProbe selection for evaporator fanP2Pr2Pr2fFt_ntEvaporator fan mode operationC_nPr2Pr2frd_ntEvaporator fan delay after defrost5Pr2Pr2frd_ntEvaporator fan ON time (with compressor OFF)0Pr2for_ntEvaporator fan OFF time (with compressor OFF)0Pr2for_ntEvaporator fan OFF time (with compressor OFF)0Pr2 <th>Lod_nt</th> <td>Probe displayed on the display</td> <td>P1</td> <td>Pr1</td>	Lod_nt	Probe displayed on the display	P1	Pr1
EdF_ntVALUE=0.01*P1+0.99*P2)0.00111EdF_ntDefrost modeinPr2tdF_ntDefrost type: electrical heating, hot gasinPr2dtF_ntProbe selection for defrost controlP2Pr2dtE_ntDefrost termination temperature8.0Pr2idF_ntInterval between two consecutives defrost cycles8Pr2ddf_ntInterval between two consecutives defrost cycles8Pr2ddf_ntStart defrost delay0Pr2dfd_ntStart defrost delay0Pr2dfd_ntDelaying during defrostitPr1dAd_ntDelay for display temperature update after any defrost10Pr1fdt_ntDraining time5Pr2Hon_ntDrain heater activated after draining time Fdt (valid if oAx=Het)00:00Pr2dAF_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FM_ntDifferential for evaporator fan regulator1.0Pr2FnC_ntEvaporator fan mode operationC_nPr2Ft_ntEvaporator fan Controlled during defrost5Pr2Ft_ntEvaporator fan ON time (with compressor OFF)0Pr2FoF_ntEvaporator fan OFF time (with compressor OFF)0Pr2	dLy_nt		00:00	Pr1
EdF_ntDefrost modeinPr2tdF_ntDefrost type: electrical heating, hot gasinPr2dFP_ntProbe selection for defrost controlP2Pr2dtE_ntDefrost termination temperature8.0Pr2idF_ntInterval between two consecutives defrost cycles8Pr2ddf_ntMaximum length for defrost15Pr2dSd_ntStart defrost delay0Pr2dFd_ntDisplaying during defrost2Pr2dFd_ntDisplaying during defrost10Pr1dAd_ntDelay for display temperature update after any defrost10Pr1fd_ntDraining time5Pr2Hon_ntDrain heater activated after draining time Fdt (valid if of oAx=Het)00:00Pr2dAF_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FATEvaporator fan stop temperature2.0Pr2FATDifferential for evaporator fan regulator1.0Pr2FR_ntEvaporator fan delay after defrost5Pr2Fnd_ntEvaporator fan delay after defrost5Pr2Fot_ntEvaporator fan controlled during defrost10Pr2Ft_ntEvaporator fan ON time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2	dtr_nt	Visualization percentage=F(P1; P2) (ex: dtr=1 means VALUE=0.01*P1+0.99*P2)	99	Pr1
dFP_ntProbe selection for defrost controlP2Pr2dtE_ntDefrost termination temperature8.0Pr2idF_ntInterval between two consecutives defrost cycles8Pr2ddF_ntMaximum length for defrost15Pr2ddd_ntStart defrost delay0Pr2dfd_ntDisplaying during defrost2Pr2dfd_ntDisplaying during defrostitPr1ddd_ntDelay for display temperature update after any defrost10Pr1fdt_ntDraining time5Pr2ddo_ntDeriost after power onnoPr2dfA_ntDefrost delay after Pull Down1Pr2dfA_ntDefrost delay after Pull Down1Pr2ffA_ntDefrost delay after Pull Down1Pr2ffA_ntEvaporator fan stop temperature2.0Pr2ffA_ntDifferential for evaporator fanP2Pr2ffA_ntDifferential of temperature5Pr2ffA_ntDifferential of temperature for forced activation of evaporator fan (o=disabled)Pr2ffLEvaporator fan Controlled during defrost5Pr2ffLDifferential of temperature for forced activation of evaporator fan (o=disabled)Pr2ffLEvaporator fan ON time (with compressor OFF)0Pr2for_ntEvaporator fan OFF time (with compressor OFF)0Pr2ffLEvaporator fan OFF time (with compressor OFF)0Pr2	EdF_nt		in	Pr2
dtE_ntDefrost termination temperature8.0Pr2idF_ntInterval between two consecutives defrost cycles8Pr2MdF_ntMaximum length for defrost15Pr2dSd_ntStart defrost delay0Pr2stc_ntCompressor stop time before starting any defrost2Pr2dFd_ntDisplaying during defrostitPr1dAd_ntDelay for display temperature update after any defrost10Pr1Fdt_ntDraining time5Pr2dPo_ntDeriost after power onnoPr2dAF_ntDefrost delay after Pull Down1Pr2dAF_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2Frd_ntDifferential for evaporator fan regulator1.0Pr2Frd_ntEvaporator fan coltrolled defrost5Pr2Fot_ntEvaporator fan controlled during defrostnoPr2Fot_ntEvaporator fan ON time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2	tdF_nt	Defrost type: electrical heating, hot gas	in	Pr2
idF_ntInterval between two consecutives defrost cycles8Pr2MdF_ntMaximum length for defrost15Pr2dSd_ntStart defrost delay0Pr2StC_ntCompressor stop time before starting any defrost2Pr2dFd_ntDisplaying during defrostitPr1dAd_ntDelay for display temperature update after any defrost10Pr1fdt_ntDraining time5Pr2Hon_ntDrain heater activated after draining time Fdt (valid if oAx=Het)00:00Pr2dAF_ntDefrost after power onnoPr2dAF_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2FNC_ntEvaporator fan delay after defrost5Pr2Fnd_ntEvaporator fan onde operationC_nPr2Ft_ntEvaporator fan controlled during defrost10Pr2Ft_ntEvaporator fan ON time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2	dFP_nt	Probe selection for defrost control	P2	Pr2
MdF_ntMaximum length for defrost15Pr2dSd_ntStart defrost delay0Pr2dSd_ntCompressor stop time before starting any defrost2Pr2dFd_ntDisplaying during defrostitPr1dAd_ntDelay for display temperature update after any defrost10Pr1Fdt_ntDraining time5Pr2Hon_ntDrain heater activated after draining time Fdt (valid if oAx=Het)00:00Pr2dAF_ntDefrost after power onnoPr2dAF_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2HyF_ntDifferential for evaporator fan regulator1.0Pr2FnC_ntEvaporator fan delay after defrost5Pr2Ft_ntEvaporator fan controlled during defrostnoPr2Ft_ntEvaporator fan ON time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2	dtE_nt	Defrost termination temperature	8.0	Pr2
dSd_ntStart defrost delay0Pr2StC_ntCompressor stop time before starting any defrost2Pr2dFd_ntDisplaying during defrostitPr1dAd_ntDelay for display temperature update after any defrost10Pr1Fdt_ntDraining time5Pr2Hon_ntDrain heater activated after draining time Fdt (valid if o0:00Pr2dPo_ntDefrost after power onnoPr2dAf_ntDefrost after power onnoPr2dAf_ntDefrost after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2HyF_ntDifferential for evaporator fan regulator1.0Pr2FnC_ntEvaporator fan delay after defrost5Pr2Fct_ntEvaporator fan controlled during defrostnoPr2Fct_ntEvaporator fan Controlled during defrostnoPr2Fo_ntEvaporator fan ON time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2	idF_nt	Interval between two consecutives defrost cycles	8	Pr2
StC_ntCompressor stop time before starting any defrost2Pr2dFd_ntDisplaying during defrostitPr1dAd_ntDelay for display temperature update after any defrost10Pr1Fdt_ntDraining time5Pr2Hon_ntDrain heater activated after draining time Fdt (valid if oAx=Het)00:00Pr2dPo_ntDefrost after power onnoPr2dAF_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2HyF_ntDifferential for evaporator fan regulator1.0Pr2FnC_ntEvaporator fan mode operationC_nPr2Fct_ntEvaporator fan controlled during defrost5Pr2Fon_ntEvaporator fan ON time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2	MdF_nt	Maximum length for defrost	15	Pr2
dFd_ntDisplaying during defrostitPr1dAd_ntDelay for display temperature update after any defrost10Pr1Fdt_ntDraining time5Pr2Hon_ntDrain heater activated after draining time Fdt (valid if oAx=Het)00:00Pr2dPo_ntDefrost after power onnoPr2dAF_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2HyF_ntDifferential for evaporator fan regulator1.0Pr2FnC_ntEvaporator fan delay after defrost5Pr2Fct_ntEvaporator fan controlled during defrostnoPr2Fon_ntEvaporator fan ON time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2	dSd_nt	Start defrost delay	0	Pr2
dAd_ntDelay for display temperature update after any defrost10Pr1Fdt_ntDraining time5Pr2Hon_ntDrain heater activated after draining time Fdt (valid if oAx=Het)00:00Pr2dPo_ntDefrost after power onnoPr2dAF_ntDefrost after power on1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2HyF_ntDifferential for evaporator fan regulator1.0Pr2FnC_ntEvaporator fan delay after defrost5Pr2Fct_ntEvaporator fan delay after defrost5Pr2Ft_ntEvaporator fan controlled during defrostnoPr2Fo_ntEvaporator fan ON time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2	StC_nt	Compressor stop time before starting any defrost	2	Pr2
dAd_ntDelay for display temperature update after any defrost10Pr1Fdt_ntDraining time5Pr2Hon_ntDrain heater activated after draining time Fdt (valid if oAx=Het)00:00Pr2dPo_ntDefrost after power onnoPr2dAf_ntDefrost after power onnoPr2dAf_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2HyF_ntDifferential for evaporator fan regulator1.0Pr2FnC_ntEvaporator fan delay after defrost5Pr2Fct_ntEvaporator fan delay after defrost5Pr2Ft_ntEvaporator fan controlled during defrostnoPr2Fo_ntEvaporator fan ON time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2	dFd_nt	Displaying during defrost	it	Pr1
Fdt_ntDraining time5Pr2Hon_ntDrain heater activated after draining time Fdt (valid if oAx=Het)00:00Pr2dPo_ntDefrost after power onnoPr2dAF_ntDefrost after power on1Pr2dAF_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2HyF_ntDifferential for evaporator fan regulator1.0Pr2FnC_ntEvaporator fan mode operationC_nPr2Fct_ntEvaporator fan delay after defrost5Pr2Fct_ntDifferential of temperature for forced activation of evaporator fan (o=disabled)10Pr2Ft_ntEvaporator fan Controlled during defrostnoPr2Fon_ntEvaporator fan ON time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2	dAd_nt	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	10	Pr1
Hon_nt         Drain heater activated after draining time Fdt (valid if oAx=Het)         00:00         Pr2           dPo_nt         Defrost after power on         no         Pr2           dAF_nt         Defrost after power on         1         Pr2           dAF_nt         Defrost delay after Pull Down         1         Pr2           FAP_nt         Probe selection for evaporator fan         P2         Pr2           FSt_nt         Evaporator fan stop temperature         2.0         Pr2           HyF_nt         Differential for evaporator fan regulator         1.0         Pr2           FnC_nt         Evaporator fan delay after defrost         5         Pr2           Fct_nt         Evaporator fan controlled during defrost         10         Pr2           Ft_nt         Evaporator fan ON time (with compressor OFF)         0         Pr2           Fof_nt         Evaporator fan OFF time (with compressor OFF)         0         Pr2			5	Pr2
dPo_nt       Defrost after power on       no       Pr2         dAF_nt       Defrost delay after Pull Down       1       Pr2         fAP_nt       Probe selection for evaporator fan       P2       Pr2         FSt_nt       Evaporator fan stop temperature       2.0       Pr2         HyF_nt       Differential for evaporator fan regulator       1.0       Pr2         FnC_nt       Evaporator fan delay after defrost       5       Pr2         Fnd_nt       Evaporator fan delay after defrost       5       Pr2         Ft_nt       Differential of temperature for forced activation of evaporator fan (o=disabled)       10       Pr2         Ft_nt       Evaporator fan Controlled during defrost       no       Pr2         Fon_nt       Evaporator fan ON time (with compressor OFF)       0       Pr2         Fof_nt       Evaporator fan OFF time (with compressor OFF)       0       Pr2		Drain heater activated after draining time Fdt (valid if	-	
dAF_ntDefrost delay after Pull Down1Pr2FAP_ntProbe selection for evaporator fanP2Pr2FSt_ntEvaporator fan stop temperature2.0Pr2HyF_ntDifferential for evaporator fan regulator1.0Pr2FnC_ntEvaporator fan mode operationC_nPr2Fnd_ntEvaporator fan delay after defrost5Pr2Fct_ntDifferential of temperature for forced activation of evaporator fan (o=disabled)10Pr2Ft_ntEvaporator fan controlled during defrostnoPr2Fon_ntEvaporator fan ON time (with compressor OFF)0Pr2Fof_ntEvaporator fan OFF time (with compressor OFF)0Pr2		,		
FAP_nt       Proble selection for evaporator fan       P2       Pr2         FSt_nt       Evaporator fan stop temperature       2.0       Pr2         HyF_nt       Differential for evaporator fan regulator       1.0       Pr2         FnC_nt       Evaporator fan mode operation       C_n       Pr2         Fnd_nt       Evaporator fan delay after defrost       5       Pr2         FCt_nt       Differential of temperature for forced activation of evaporator fan (o=disabled)       10       Pr2         Ft_nt       Evaporator fan controlled during defrost       no       Pr2         Fon_nt       Evaporator fan ON time (with compressor OFF)       0       Pr2         FoF_nt       Evaporator fan OFF time (with compressor OFF)       0       Pr2		· · ·	-	
FSt_nt     Evaporator fan stop temperature     2.0     Pr2       HyF_nt     Differential for evaporator fan regulator     1.0     Pr2       FnC_nt     Evaporator fan mode operation     C_n     Pr2       Fnd_nt     Evaporator fan delay after defrost     5     Pr2       FCt_nt     Differential of temperature for forced activation of evaporator fan (o=disabled)     10     Pr2       Ft_nt     Evaporator fan controlled during defrost     no     Pr2       Fon_nt     Evaporator fan ON time (with compressor OFF)     0     Pr2       Fof_nt     Evaporator fan OFF time (with compressor OFF)     0     Pr2				
HyF_nt         Differential for evaporator fan regulator         1.0         Pr2           FnC_nt         Evaporator fan mode operation         C_n         Pr2           Fnd_nt         Evaporator fan delay after defrost         5         Pr2           Fct_nt         Differential of temperature for forced activation of evaporator fan (o=disabled)         10         Pr2           Ft_nt         Evaporator fan controlled during defrost         no         Pr2           Fon_nt         Evaporator fan ON time (with compressor OFF)         0         Pr2           FoF_nt         Evaporator fan OFF time (with compressor OFF)         0         Pr2				
FnC_nt         Evaporator fan mode operation         C_n         Pr2           Fnd_nt         Evaporator fan delay after defrost         5         Pr2           FCt_nt         Differential of temperature for forced activation of evaporator fan (o=disabled)         10         Pr2           Ft_nt         Evaporator fan controlled during defrost         no         Pr2           Fon_nt         Evaporator fan ON time (with compressor OFF)         0         Pr2           FoF_nt         Evaporator fan OFF time (with compressor OFF)         0         Pr2				
Fnd_nt     Evaporator fan delay after defrost     5     Pr2       FCt_nt     Differential of temperature for forced activation of evaporator fan (o=disabled)     10     Pr2       Ft_nt     Evaporator fan controlled during defrost     no     Pr2       Fon_nt     Evaporator fan ON time (with compressor OFF)     0     Pr2       FoF_nt     Evaporator fan OFF time (with compressor OFF)     0     Pr2	• -		-	
FCt_nt         Differential of temperature for forced activation of evaporator fan (o=disabled)         10         Pr2           Ft_nt         Evaporator fan controlled during defrost         no         Pr2           Fon_nt         Evaporator fan ON time (with compressor OFF)         0         Pr2           Fof_nt         Evaporator fan OFF time (with compressor OFF)         0         Pr2				
Ft_nt     Evaporator fan (o=oisabled)     Pr2       Fon_nt     Evaporator fan ON time (with compressor OFF)     0     Pr2       FoF_nt     Evaporator fan OFF time (with compressor OFF)     0     Pr2	-		-	
Fon_nt         Evaporator fan ON time (with compressor OFF)         0         Pr2           FoF_nt         Evaporator fan OFF time (with compressor OFF)         0         Pr2		evaporator fan (o=disabled)		
FoF_nt         Evaporator fan OFF time (with compressor OFF)         0         Pr2	-			
			-	
FAU_nt         Probe selection for condenser fan         nP         Pr2			-	
St2_nt Regulation Set Point 2 for condenser fan 0.0 Pr2		•		
Hy2_nt         Differential for Set Point 2 for condenser fan regulator         1.0         Pr2	Hy2_nt	Differential for Set Point 2 for condenser fan regulator	1.0	Pr2

EMERSON

## Installing and operating instructions

FCC_nt	Condenser fan mode operation	O_n	Pr2
FCo_nt	Condenser fan on after switching off the compressor	0	Pr2
ACH_nt	Kind of action for auxiliary regulator	CL	Pr2
SAA_nt	Set point for auxiliary regulator	0.0	Pr2
SHy_nt	Differential for auxiliary regulator	1.0	Pr2
ArP_nt	Probe selection for auxiliary regulator	nP	Pr2
Sdd_nt	Auxiliary regulator disabled during any defrost	no	Pr2
ALP_nt	Probe selection for temperature alarms	P1	Pr1
ALC_nt	Temperature alarms configuration: relative, absolute	rE	Pr1
ALU_nt	Maximum temperature alarm	5.0	Pr1
ALL_nt	Minimum temperature alarm	5.0	Pr1
AFH_nt	Temperature alarm recovery differential	1.0	Pr1
ALd_nt	Temperature alarm delay	15	Pr1
dAo_nt	Temperature alarm delay after power-on	01:30	Pr1
AP2_nt	Probe selection for second temperature alarms	nP	Pr2
AL2_nt	Second low temperature alarm	-100.0	Pr2
AU2_nt	Second high temperature alarm	150.0	Pr2
AH2_nt	Differential for second temperature alarm recovery	2.0	Pr2
Ad2_nt	Second temperature alarm delay	5	Pr2
dA2_nt	Delay for second temperature alarm after power-on	01:00	Pr2
bLL_nt	Compressor off due to second low temperature alarm	no	Pr2
AC2_nt	Compressor off due to second high temperature alarm	yes	Pr2
SAF_nt	Differential for anti freezing control	3.0	Pr2
tbA_nt	Alarm relay switched off by pushing any key	yes	Pr2
oA1_nt	Relay output oA1 configuration	dEF	Pr2
oA2_nt	Relay output oA2 configuration	Fan	Pr2
oA3_nt	Relay output oA3 configuration	LiG	Pr2
oA4_nt	Relay output oA4 configuration	ALr	Pr2
oAn_nt	Analogue output configuration	FrE	Pr2
AOP_nt	Alarm relay polarity	CL	Pr2
i1P_nt	Digital input 1 polarity	CL	Pr1
i1F_nt	Digital input 1 configuration	dor	Pr1
i2P_nt	Digital input / configuration	CL	Pr2
	Digital input 2 polarity	EAL	Pr2
i2F_nt		1	Pr2
did_nt	Digital inputs 1 alarm delay	1	
d2d_nt	Digital inputs 2 alarm delay Number of pressure alarm switch before stopping the		Pr2
nPS_nt	regulation (Lock alarm)	15	Pr1
OdC_nt	Compressor and fan status after door opening	F-C	Pr1
rrd_nt	Regulation restart after open door alarm	yes	Pr1
HES_nt	Differential for energy saving mode Energy saving mode controls the lights (lights off	0	Pr1
LdE_nt	when energy saving goes active)	yes	Pr1
Hur_nt	Hours		Pr1
Min_nt	Minutes		Pr1
dAY_nt	Day of the week		Pr1
dyM_nt	Day of the month		Pr1
Mon_nt	Month		Pr1
yAr_nt	Year		Pr1
Hd1_nt	First day of week end	Sat	Pr2
Hd2_nt	Second day of week end	Sun	Pr2
iLE_nt	Working days Energy saving starting time	00:00	Pr2
dLE_nt	Working days Energy saving duration	00:00	Pr2
iSE_nt	Holyday Energy saving starting time	00:00	Pr2
dSE_nt	Holyday Energy saving duration	00:00	Pr2
dd1_nt	Sunday defrost	no	Pr2
dd2_nt	Monday defrost	no	Pr2
dd3_nt	Tuesday defrost	no	Pr2
	Wednesday defrost	no	Pr2
dd4_nt	weunesudy denost		

dd6_nt	Friday defrost	no	Pr2
dd7_nt	Saturday defrost	no	Pr2
Ld1_nt	1st defrost starting time	nu	Pr2
Ld2_nt	2nd defrost starting time	nu	Pr2
Ld3_nt	3rd defrost starting time	nu	Pr2
Ld4_nt	4th defrost starting time	nu	Pr2
Ld5_nt	5th defrost starting time	nu	Pr2
Ld6_nt	6th defrost starting time	nu	Pr2
Adr_nt	Serial address	1	Pr2
bAU_nt	Baud rate selection for serial port	9.6	Pr2
onC_nt	ONOFF button configuration	ES	Pr2
on2_nt	ONOFF button timed (3sec) configuration	oFF	Pr2
LG2_nt	Light button timed (3sec) configuration	nU	Pr2
dn2_nt	Down button timed (3sec) configuration	Lnt	Pr2
dP1_nt	Probe P1 value visualization		Pr1
dP2_nt	Probe P2 value visualization		Pr1
dP3_nt	Probe P3 value visualization		Pr1
dP4_nt	Probe P4 value visualization		Pr1
SPd_nt	Instantaneous compressor speed (in Hz)		Pr1
rSE_nt	Real regulation Set Point		Pr1
rEL_nt	Firmware release		Pr1
Ptb_nt	Parameter map code	1	Pr1

EMERSON

DIXELL



Dixell S.r.l. - Z.I. Via dell'Industria, 27 - 32016 Alpago (BL) ITALY Tel. +39.0437.9833 r.a. - Fax +39.0437.989313 - EmersonClimate.com/Dixell - dixell@emerson.com